



# Z8932301ZEM

## DSP FAMILY EMULATOR— Z89323

### FEATURES

■ Supported Devices:

| Packages    | Emulation               | OTP Programming     |
|-------------|-------------------------|---------------------|
| 44-Pin PLCC | Z89223/273 <sup>1</sup> | Z89273 <sup>2</sup> |
| 44-Pin QFP  | Z89223 <sup>1</sup>     | N/A                 |
| 68-Pin PLCC | Z89323/373 <sup>1</sup> | Z89373 <sup>3</sup> |
| 80-Pin QFP  | Z89323/373 <sup>1</sup> | Z89373 <sup>3</sup> |

**Notes:**

1. Requires hand-wiring the Z89323 Emulator board to your target board's socket or by using a daughterboard connected to JP2 and JP3.
2. Requires optional, separately purchased accessory kit, Z8922300ZAC, from Zilog.
3. Requires optional, separately purchased accessory kit, Z8937300ZAC, from Zilog.

- ICEBOX Emulator Provides Source-Level Debugging for DSP Codes.
- Symbolic Disassembly in the Debug Window
- Selectable Baud Rates – 9600 to 57.6 Kbps
- Windows-Based User Interface
- RS-232C Connector
- Zilog Macro Cross Assembler (ZMASM)
  - Structured Assembly and Data Code
  - Source-Level Debug Support
  - Built-In Register Equates
  - Linker

### GENERAL DESCRIPTION

Zilog's in-circuit emulators are interactive, Windows-oriented development tools providing a real-time environment for developing and debugging software. Also included is a full-featured macro cross assembler to enhance programmer productivity when used in conjunction with the Z89323 Emulator.

The Emulator provides a hardware platform that is a significant improvement compared to software simulators. The Emulator is faster in operation, making it more practical than software simulators for code development.

The Z89323 Emulator, which supports the Z89323 family of DSP processors listed above, provides essential timing and I/O circuitry to simplify user emulation of the prototype hardware and software product.

The Z89323 Emulator can be connected to a serial port (COM1, COM2, COM3, or COM4) of the host computer, and it uses Graphical User Interface (GUI) software.

## SPECIFICATIONS

### Operating Conditions

|                          |   |
|--------------------------|---|
| Operating Temperature:   | 20°C ±10°C                                |
| Supply Voltage:          | +5 VDC ±5% or 9VDC @<br>1.2A wall adaptor |
| Operating Humidity:      | 10-90% RH<br>(non-condensing)             |
| Minimum Emulation Speed: | 1 MHz                                     |
| Maximum Emulation Speed: | 20 MHz                                    |

### Power Requirements

The emulator board has dual-power capability: 9VDC or 5.0VDC. If optional OTP programming is enabled and the 5.0VDC terminal is used, a 6.0VDC +/-5% @ 500 mA (typical) power source is also required.

### Dimensions

|         |          |
|---------|----------|
| Width:  | 5.25 in. |
| Length: | 9.50 in. |
| Height: | 0.50 in. |

### Serial Interface

RS-232C @ 9600, 19200 (default), 28800, or 57600 Baud Rates

### Emulation Memory

DSP = 64K words (maximum)

### Number of Breakpoints

DSP = 256 (maximum)

## HOST COMPUTER

### Minimum Requirements

IBM PC (or 100-percent compatible) 386-based machine:

- 33 MHz
- 4 MB RAM
- VGA Video Adapter
- Hard Disk Drive (3.0 MB free space)
- 3.5-inch, High-Density (HD) Floppy Disk Drive
- RS-232C COM Port
- Mouse or Pointing Device
- Microsoft Windows 3.1(Use with DSPICE software)

The following changes to the Minimum Requirements are recommended for increased performance:

- 486- or Pentium-based machine
- 66 MHz (or faster)
- 8 MB of RAM (or more)
- SVGA Video Adapter
- Color Monitor
- Printer
- Microsoft Windows 95

## KIT CONTENTS

### Qty. Item

1 Z89323 Emulator Board

### Cables/Pods

- 1 RS-232C Serial Cable, 9-Pin M-F
- 1 9VDC AC Adaptor

### Host Software

- DSP GUI Diskette
- ZDS/Zilog Macro Cross Assembler Diskette

### Documentation

- Emulator User's Manual
- Zilog Macro Cross Assembler User's Manual
- Software License and Limited Warranty Agreement
- Registration Card (2)

**ADDITIONAL REQUIRED ITEMS NOT SUPPLIED**

## ■ Your Target Design

Typically, this is a wire-wrapped or printed-circuit prototype that includes connectors that you can

connect to the emulator's JP2 and JP3, or points where you can connect with the emulator P6.

**LIMITATIONS**

1. Switching Emulators without quitting the GUI is not supported and may cause unexpected results.
2. The Emulator breakpoint hardware does not distinguish between instruction and data fetches. Consequently, the breakpoint hardware triggers when the address specified matches either an instruction or data fetch.
3. "ROM PROTECT" option programming is temporarily disabled.
4. The maximum loadable symbols is 32,768 provided there is enough system resource (memory).
5. Although GUI , 3.00 and later support baud rates up to 57.6K baud, the actual maximum usable rate may be less due to limitations of the users hardware and or system software setup. The maximum usable rate is determined by the users tolerance of the frequency of communication errors.
6. The GUI does not recognize the PUSH and POP instructions when entered in the In-Line Assembler (Debug window). As a workaround, use "LD STACK,xxx" for PUSH and "LD xxx,STACK" for POP.

**Example:**

```
0000    LD    A, #%0006
0002    ADD  A, #%0002
0003    LD    Y, @A
0004    NOP
0005    NOP
0006    JP    %0000
0008    NOP
```

Setting the breakpoint at %0008 and click GO causes the code to break at %0004 due to the data fetch address match during the prior instruction. This does

## PRECAUTIONS

1. The Emulator cannot be operated while performing ESD/EMI testing on the target board.
2. For 386 PCs, set the baud rate to 19.2K or less because Windows' communication driver does not guarantee "reliable" operation at more than 9600 baud. Selecting a high baud rate on some slower 386 machines may crash the Windows environment.
3. Breakpoint overshoot. The Debug window shows the processor halting at one or two instructions past the instruction where the breakpoint was set.
4. Do not start the Emulator with OTP in socket.
5. Executing GUI. The GUI will occasionally continue to indicate "Executing" after a Halt instruction. Pushing the GO button will then result in Executing. (Executing showing at the top of the screen.)

---

© 1997 by Zilog, Inc. All rights reserved. No part of this document may be copied or reproduced in any form or by any means without the prior written consent of Zilog, Inc. The information in this document is subject to change without notice. Devices sold by Zilog, Inc. are covered by warranty and patent indemnification provisions appearing in Zilog, Inc. Terms and Conditions of Sale only. Zilog, Inc. makes no warranty, express, statutory, implied or by description, regarding the information set forth herein or regarding the freedom of the described devices from intellectual property infringement. Zilog, Inc. makes no warranty of merchantability or fitness for any purpose. Zilog, Inc. shall not be responsible for any errors that may appear in this document. Zilog, Inc. makes no commitment to update or keep current the information contained in this document.

The software described herein is provided on an "as is" basis and without warranty. Zilog accepts no liability for incidental or consequential damages arising from use of the software.

Zilog's products are not authorized for use as critical components in life support devices or systems unless a specific written agreement pertaining to such intended use is executed between the customer and Zilog prior to use. Life support devices or systems are those which are intended for surgical implantation into the body, or which sustains life whose failure to perform, when properly used in accordance with instructions for use provided in the labeling, can be reasonably expected to result in significant injury to the user.

Zilog, Inc. 210 East Hacienda Ave.  
Campbell, CA 95008-6600  
Telephone (408) 370-8000  
FAX 408 370-8056  
Internet: <http://www.zilog.com>