

ADSP-21375 EZ-KIT Lite® Evaluation System Manual

Revision 1.1, September 2007

Part Number
82-000940-02

Analog Devices, Inc.
One Technology Way
Norwood, Mass. 02062-9106



Copyright Information

©2007 Analog Devices, Inc., ALL RIGHTS RESERVED. This document may not be reproduced in any form without prior, express written consent from Analog Devices, Inc.

Printed in the USA.

Limited Warranty

The EZ-KIT Lite evaluation system is warranted against defects in materials and workmanship for a period of one year from the date of purchase from Analog Devices or from an authorized dealer.

Disclaimer

Analog Devices, Inc. reserves the right to change this product without prior notice. Information furnished by Analog Devices is believed to be accurate and reliable. However, no responsibility is assumed by Analog Devices for its use; nor for any infringement of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under the patent rights of Analog Devices, Inc.

Trademark and Service Mark Notice

The Analog Devices icon bar and logo, VisualDSP++, the VisualDSP++ logo, SHARC, the SHARC logo, CROSSCORE, the CROSSCORE logo, EZ-KIT Lite, and EZ-Extender are registered trademarks of Analog Devices, Inc.

All other brand and product names are trademarks or service marks of their respective owners.

Regulatory Compliance

The ADSP-21375 EZ-KIT Lite is designed to be used solely in a laboratory environment. The board is not intended for use as a consumer end product or as a portion of a consumer end product. The board is an open system design which does not include a shielded enclosure and therefore may cause interference to other electrical devices in close proximity. This board should not be used in or near any medical equipment or RF devices.

The ADSP-21375 EZ-KIT Lite has been certified to comply with the essential requirements of the European EMC directive 89/336/EEC amended by 93/68/EEC and therefore carries the “CE” mark.

The ADSP-21375 EZ-KIT Lite has been appended to Analog Devices, Inc. Technical Construction File (TCF) referenced ‘DSPTOOLS1’ dated December 21, 1997 and was awarded CE Certification by an appointed European Competent Body as listed below.

Technical Certificate No: Z600ANA1.027

Issued by: Technology International (Europe) Limited
60 Shrivenham Hundred Business Park
Shrivenham, Swindon, SN6 8TY, UK



The EZ-KIT Lite evaluation system contains ESD (electrostatic discharge) sensitive devices. Electrostatic charges readily accumulate on the human body and equipment and can discharge without detection. Permanent damage may occur on devices subjected to high-energy discharges. Proper ESD precautions are recommended to avoid performance degradation or loss of functionality. Store unused EZ-KIT Lite boards in the protective shipping package.



CONTENTS

PREFACE

Purpose of This Manual	xiii
Intended Audience	xiii
Manual Contents	xiv
What's New in This Manual	xiv
Technical or Customer Support	xv
Supported Processors	xv
Product Information	xvi
MyAnalog.com	xvi
Processor Product Information	xvi
Related Documents	xvii
Online Technical Documentation	xviii
Accessing Documentation From VisualDSP++	xix
Accessing Documentation From Windows	xix
Accessing Documentation From Web	xx
Printed Manuals	xx
Hardware Tools Manuals	xx
Processor Manuals	xx
Data Sheets	xxi

CONTENTS

Notation Conventions	xxi
----------------------------	-----

USING ADSP-21375 EZ-KIT LITE

Package Contents	1-2
Default Configuration	1-3
Installation and Session Startup	1-5
Evaluation License Restrictions	1-7
External Memory	1-7
ELVIS Interface	1-9
Analog Audio	1-10
LEDs and Push Buttons	1-11
Example Programs	1-13
Background Telemetry Channel	1-13

ADSP-21375 EZ-KIT LITE HARDWARE REFERENCE

System Architecture	2-2
External Port	2-3
DAI Interface	2-4
DPI Interface	2-5
FLAG Pins	2-6
External PLL	2-7
Expansion Interface	2-7
JTAG Emulation Port	2-8
Switch Settings	2-9
Boot Mode and Clock Ratio Select Switch (SW2)	2-10

Codec Setup Switch (SW3)	2-11
Electret Microphone Select Switch (SW4)	2-12
UART Enable Switch (SW5)	2-12
Loop-Back Test Switches (SW6 and SW14)	2-12
Push Button Enable Switch (SW7)	2-13
ELVIS Oscilloscope Configuration Switch (SW1)	2-13
ELVIS Function Generator Configuration Switch (SW13)	2-14
AD1835A and Flash Disconnect Switch (SW15)	2-15
LEDs and Push Buttons	2-15
General Purpose LEDs (LED1–8)	2-16
Power LED (LED9)	2-16
Reset LED (LED10)	2-16
USB Monitor LED (ZLED3)	2-16
Push Buttons (SW8–11)	2-17
Board Reset Push Button (SW12)	2-17
Jumpers	2-18
VCO Select Jumper (JP1)	2-19
ELVIS Select Jumper (JP2)	2-19
ELVIS Voltage Selection Jumper (JP3)	2-20
ELVIS Programmable Flag Jumper (JP4)	2-20
Connectors	2-21
Expansion Interface Connectors (J1–3)	2-22
Audio In RCA Connector (J10)	2-22
Audio Out RCA Connector (J5)	2-22

CONTENTS

Headphone Out Jack (J9)	2-23
Power Jack (J4)	2-23
S/PDIF Coax Connectors (J7 and J8)	2-24
DPI Header (P3)	2-24
DAI Header (P4)	2-24
JTAG Header (ZP4)	2-25

ADSP-21375 EZ-KIT LITE BILL OF MATERIALS

ADSP-21375 EZ-KIT LITE SCHEMATIC

Title Page	B-1
ADSP-21375 Processor	B-2
ADSP-21375 Processor 2	B-3
Memory	B-4
Analog Audio	B-5
Audio Out 1	B-6
Audio Out 2	B-7
Audio In and Headphone Out	B-8
External PLL, S/PDIF, and RS-232	B-9
ELVIS Interface	B-10
Push Buttons, LEDs, and RESET	B-11
Expansion Interface	B-12
Power	B-13

INDEX

PREFACE


Thank you for purchasing the ADSP-21375 EZ-KIT Lite[®], Analog Devices, Inc. evaluation system for ADSP-21375 SHARC[®] processors.

The SHARC processors are based on a 32-bit super Harvard architecture that includes a unique memory architecture comprised of two large on-chip, dual-ported SRAM blocks coupled with a sophisticated IO processor, which gives a SHARC processor the bandwidth for sustained high-speed computations. SHARC processors represents today's de facto standard for floating-point processing, targeted toward premium audio applications.

The evaluation system is designed to be used in conjunction with the VisualDSP++[®] development environment to test the capabilities of the ADSP-21375 SHARC processors. The VisualDSP++ development environment gives you the ability to perform advanced application code development and debug, such as:

- Create, compile, assemble, and link application programs written in C++, C, and ADSP-21375 assembly
- Load, run, step, halt, and set breakpoints in application program
- Read and write data and program memory
- Read and write core and peripheral registers
- Plot memory

Access to the ADSP-21375 processor from a personal computer (PC) is achieved through a USB port or an optional JTAG emulator. The USB interface gives unrestricted access to the ADSP-21375 processor and the evaluation board peripherals. Analog Devices JTAG emulators offer faster communication between the host PC and target hardware. Analog Devices carries a wide range of in-circuit emulation products. To learn more about Analog Devices emulators and processor development tools, go to <http://www.analog.com/dsp/tools/>.

 The ADSP-21375 EZ-KIT Lite installation is part of the VisualDSP++ installation. The EZ-KIT Lite is a licensed product that offers an unrestricted evaluation license for the first 90 days. For details about evaluation license restrictions after the 90 days, refer to “[Evaluation License Restrictions](#)” on page 1-7.

ADSP-21375 EZ-KIT Lite provides example programs to demonstrate the capabilities of the evaluation board.

The board features:

- Analog Devices ADSP-21375 processor
 - ✓ 208-pin MQFP package
 - ✓ 266 MHz core clock speed
- Synchronous dynamic random access memory (SDRAM)
 - ✓ 2M x 16-bit x 4 banks
- Flash memory
 - ✓ 1M x 8-bit

- Serial peripheral interface (SPI) flash memory
 - ✓ 2 Mbit
- Analog audio interface
 - ✓ AD1835A codec
 - ✓ 4x2 RCA phono jack for 4 channels of stereo output
 - ✓ 2x1 RCA phono jack for 1 channel of stereo input
 - ✓ 3.5 mm headphone jack for 1 channel stereo output
- Universal asynchronous receiver/transmitter (UART)
 - ✓ ADM3202 RS-232 driver/receiver
 - ✓ DB9 female connector
- National Instruments Educational Laboratory Virtual Instrumentation Suite (ELVIS) Interface
 - ✓ LabVIEW™-based virtual instruments
 - ✓ Multifunction data acquisition device
 - ✓ Bench-top workstation and prototype board
- LEDs
 - ✓ 11 LEDs: 1 power (green), 1 board reset (red), 1 USB monitor (amber), and 8 general purpose (amber)
- Push buttons
 - ✓ 5 push buttons: 1 reset, 2 connected to DAI, 2 connected to the FLAG pins of the processor

- Expansion interface (Type A)
 - ✓ Parallel port, FLAG pins, DPI, DAI
- Other features
 - ✓ JTAG ICE 14-pin header
 - ✓ Test points for processor current measurement
 - ✓ DPI header
 - ✓ DAI header

The EZ-KIT Lite board has a total of 1 MB of parallel flash memory and 2 Mbit of SPI flash memory. The flash memories can store user-specific boot code, allowing the board to run as a stand-alone unit. For more information, see [“External Memory” on page 1-7](#) and [“Boot Mode and Clock Ratio Select Switch \(SW2\)” on page 2-10](#). The board has 16 MB of SDRAM, which can be used at runtime or from which code can be executed.

The DAI port of the processor connects to the AD1835A audio codec and an external phase lock loop (PLL). The DAI interface facilitates development of digital and analog audio signal-processing applications. See [“Analog Audio” on page 1-10](#) and for more information.

The DPI port of the processor connects to the UART interface and the SPI interface. The UART interface can connect to a standard RS-232 connection, while the SPI connects to the 2 Mbit of serial flash memory.

Additionally, the EZ-KIT Lite board provides access to all of the processor’s peripheral ports. Access is provided in the form of a three-connector expansion interface. See [“Expansion Interface” on page 2-7](#) for details.

Purpose of This Manual

The *ADSP-21375 EZ-KIT Lite Evaluation System Manual* provides instructions for installing the product hardware (board) and describes the operation and configuration of the board components. The product software component is detailed in the *VisualDSP++ Installation Quick Reference Card*. The manual provides guidelines for running your own code on the ADSP-21375 EZ-KIT Lite. Finally, a schematic and a bill of materials are provided as a reference for future designs.

Intended Audience

The primary audience for this manual is a programmer who is familiar with Analog Devices processors. This manual assumes that the audience has a working knowledge of the appropriate processor architecture and instruction set. Programmers who are unfamiliar with Analog Devices processors can use this manual but should supplement it with other texts, such as the *ADSP-2136x SHARC Processor Programming Reference* and *ADSP-21368 SHARC Processor Hardware Reference* (includes ADSP-21375) that describe your target architecture.

Programmers who are unfamiliar with VisualDSP++ should refer to the VisualDSP++ online Help and the VisualDSP++ user's or getting started guides. For the locations of these documents, see [“Related Documents”](#).

Manual Contents

The manual consists of:

- Chapter 1, “[Using ADSP-21375 EZ-KIT Lite](#)” on page 1-1
Provides information on the EZ-KIT Lite from a programmer’s perspective and provides an easy-to-access memory map.
- Chapter 2, “[ADSP-21375 EZ-KIT Lite Hardware Reference](#)” on page 2-1
Provides information on the hardware aspects of the evaluation system.
- Appendix A, “[ADSP-21375 EZ-KIT Lite Bill Of Materials](#)” on page A-1
Provides a list of components used to manufacture the EZ-KIT Lite board.
- Appendix B, “[ADSP-21375 EZ-KIT Lite Schematic](#)” on page B-1
Provides the resources to allow modifications to the EZ-KIT Lite or to use as a reference design.



Appendix B now is part of the online Help. The PDF version of the *ADSP-21375 EZ-KIT Lite Evaluation System Manual* is located in the Docs\EZ-KIT Lite Manuals folder on the installation CD. Alternatively, the schematic can be found on the Analog Devices Web site at <http://www.analog.com/processors>.

What’s New in This Manual

The *ADSP-21375 EZ-KIT Lite Evaluation System Manual* has been updated for the current revision of VisualDSP++.

Appendix B, “[ADSP-21375 EZ-KIT Lite Schematic](#)” on page B-1 have been updated to reflect the latest revision of the board.

Technical or Customer Support

You can reach Analog Devices, Inc. Customer Support in the following ways:

- Visit the Embedded Processing and DSP products Web site at <http://www.analog.com/processors/technicalSupport>
- E-mail tools questions to processor.tools.support@analog.com
- E-mail processor questions to processor.support@analog.com (World wide support)
processor.europe@analog.com (Europe support)
processor.china@analog.com (China support)
- Phone questions to 1-800-ANALOGD
- Contact your Analog Devices, Inc. local sales office or authorized distributor
- Send questions by mail to:
Analog Devices, Inc.
One Technology Way
P.O. Box 9106
Norwood, MA 02062-9106
USA

Supported Processors

The ADSP-21375 EZ-KIT Lite evaluation system supports the Analog Devices ADSP-21375 SHARC processors.

Product Information

You can obtain product information from the Analog Devices Web site, from the product CD-ROM, or from the printed publications (manuals).

Analog Devices is online at <http://www.analog.com>. Our Web site provides information about a broad range of products—analogue integrated circuits, amplifiers, converters, and digital signal processors.

MyAnalog.com

MyAnalog.com is a free feature of the Analog Devices Web site that allows customization of a Web page to display only the latest information on products you are interested in. You can also choose to receive weekly e-mail notifications containing updates to the Web pages that meet your interests. MyAnalog.com provides access to books, application notes, data sheets, code examples, and more.

Registration:

Visit <http://www.myanalog.com> to sign up. Click **Register** to use MyAnalog.com. Registration takes about five minutes and serves as means for you to select the information you want to receive.

If you are already a registered user, just log on. Your user name is your e-mail address.

Processor Product Information

For information on embedded processors and DSPs, visit our Web site at <http://www.analog.com/processors>, which provides access to technical publications, data sheets, application notes, product overviews, and product announcements.

You may also obtain additional information about Analog Devices and its products in any of the following ways.

- E-mail questions or requests for information to
processor.support@analog.com (World wide support)
processor.europe@analog.com (Europe support)
processor.china@analog.com (China support)
- Fax questions or requests for information to
1-781-461-3010 (North America)
+49-89-76903-157 (Europe)

Related Documents

For information on product related development software and hardware, see these publications:

Table 1. Related Processor Publications

Title	Description
<i>ADSP-21375: 266 MHz High Performance SHARC Processor Preliminary Data Sheet</i>	General functional description, pinout, and timing
<i>ADSP-21368 SHARC Processor Hardware Reference (Includes ADSP-21367, ADSP-21368, ADSP-21369, ADSP-21371, ADSP-21375)</i>	Description of internal processor architecture, registers, and all peripheral functions
<i>ADSP-2136x SHARC Processor Programming Reference</i>	Description of all allowed processor assembly instructions


Table 2. Related VisualDSP++ Publications

<i>VisualDSP++ User's Guide</i>	Detailed description of VisualDSP++ features and usage
<i>VisualDSP++ Assembler and Preprocessor Manual</i>	Description of the assembler function and commands

Product Information

Table 2. Related VisualDSP++ Publications (Cont'd)

<i>VisualDSP++ C/C++ Compiler Manual for SHARC Processors</i>	Description of the compiler function and commands for SHARC processors
<i>VisualDSP++ Run-Time Library Manual for SHARC Processors</i>	Description of the run-time library functions for SHARC processors
<i>VisualDSP++ Linker and Utilities Manual</i>	Description of the linker function and commands
<i>VisualDSP++ Loader and Utilities Manual</i>	Description of the loader function and commands

 If you plan to use the EZ-KIT Lite board in conjunction with a JTAG emulator, also refer to the documentation that accompanies the emulator.

All documentation is available online. Most documentation is available in printed form.

Visit the Technical Library Web site to access all processor and tools manuals and data sheets:

<http://www.analog.com/processors/technicalSupport/technicalLibrary/>.

Online Technical Documentation

Online documentation comprises the VisualDSP++ Help system, software tools manuals, hardware tools manuals, processor manuals, the Dinkum Abridged C++ library, and Flexible License Manager (FlexLM) network license manager software documentation. You can easily search across the entire VisualDSP++ documentation set for any topic of interest. For easy printing, supplementary .pdf files of most manuals are provided in the Docs folder on the VisualDSP++ installation CD.

Each documentation file type is described as follows.

File	Description
.chm	Help system files and manuals in Help format
.htm or .html	Dinkum Abridged C++ library and FlexLM network license manager software documentation. Viewing and printing the .html files requires a browser, such as Internet Explorer 6.0 (or higher).
.pdf	VisualDSP++ and processor manuals in Portable Documentation Format (PDF). Viewing and printing the .pdf files requires a PDF reader, such as Adobe Acrobat Reader (4.0 or higher).

If documentation is not installed on your system as part of the software installation, you can add it from the VisualDSP++ CD at any time by running the Tools installation. Access the online documentation from the VisualDSP++ environment, Windows[®] Explorer, or the Analog Devices Web site.

Accessing Documentation From VisualDSP++

To view VisualDSP++ Help, click on the **Help** menu item or go to the Windows task bar and navigate to the VisualDSP++ documentation via the **Start** menu.

To view ADSP-21375 EZ-KIT Lite Help, which is part of the VisualDSP++ Help system, use the **Contents** or **Search** tab of the Help window.

Accessing Documentation From Windows

In addition to any shortcuts you may have constructed, there are many ways to open VisualDSP++ online Help or the supplementary documentation from Windows.

Help system files (.chm) are located in the `Help` folder, and .pdf files are located in the `Docs` folder of your VisualDSP++ installation CD-ROM. The `Docs` folder also contains the Dinkum Abridged C++ library and the FlexLM network license manager software documentation.

Product Information

Your software installation kit includes online Help as part of the Windows interface. These help files provide information about VisualDSP++ and the ADSP-21375 EZ-KIT Lite evaluation system.

Accessing Documentation From Web

Download manuals at the following Web site:

<http://www.analog.com/processors/technicalSupport/technicalLibrary/>.

Select a processor family and book title. Download archive (.zip) files, one for each manual. Use any archive management software, such as WinZip, to decompress downloaded files.

Printed Manuals

For general questions regarding literature ordering, call the Literature Center at 1-800-ANALOGD (1-800-262-5643) and follow the prompts.

Hardware Tools Manuals

To purchase EZ-KIT Lite and in-circuit emulator (ICE) manuals, call 1-603-883-2430. The manuals may be ordered by title or by product number located on the back cover of each manual.

Processor Manuals

Hardware reference and instruction set reference manuals may be ordered through the Literature Center at 1-800-ANALOGD (1-800-262-5643), or downloaded from the Analog Devices Web site. Manuals may be ordered by title or by product number located on the back cover of each manual.

Data Sheets

All data sheets (preliminary and production) may be downloaded from the Analog Devices Web site. Only production (final) data sheets (Rev. 0, A, B, C, and so on) can be obtained from the Literature Center at 1-800-ANALOGD (1-800-262-5643); they also can be downloaded from the Web site.




To have a data sheet faxed to you, call the Analog Devices Faxback System at 1-800-446-6212. Follow the prompts and a list of data sheet code numbers will be faxed to you. If the data sheet you want is not listed, check for it on the Web site.

Notation Conventions

Text conventions used in this manual are identified and described as follows.

Example	Description
Close command (File menu)	Titles in reference sections indicate the location of an item within the VisualDSP++ environment's menu system (for example, the Close command appears on the File menu).
{this that}	Alternative required items in syntax descriptions appear within curly brackets and separated by vertical bars; read the example as <i>this</i> or <i>that</i> . One or the other is required.
[this that]	Optional items in syntax descriptions appear within brackets and separated by vertical bars; read the example as an optional <i>this</i> or <i>that</i> .
[this,...]	Optional item lists in syntax descriptions appear within brackets delimited by commas and terminated with an ellipsis; read the example as an optional comma-separated list of <i>this</i> .
.SECTION	Commands, directives, keywords, and feature names are in text with letter gothic font.
<i>filename</i>	Non-keyword placeholders appear in text with italic style format.

Notation Conventions

Example	Description
	<p>Note: For correct operation, ...</p> <p>A Note provides supplementary information on a related topic. In the online version of this book, the word Note appears instead of this symbol.</p>
	<p>Caution: Incorrect device operation may result if ...</p> <p>Caution: Device damage may result if ...</p> <p>A Caution identifies conditions or inappropriate usage of the product that could lead to undesirable results or product damage. In the online version of this book, the word Caution appears instead of this symbol.</p>
	<p>Warning: Injury to device users may result if ...</p> <p>A Warning identifies conditions or inappropriate usage of the product that could lead to conditions that are potentially hazardous for the devices users. In the online version of this book, the word Warning appears instead of this symbol.</p>

1 USING ADSP-21375 EZ-KIT LITE

This chapter provides specific information to assist you with development of programs for the ADSP-21375 EZ-KIT Lite evaluation system.

The information appears in the following sections.

- [“Package Contents” on page 1-2](#)
Lists the items contained in your ADSP-21375 EZ-KIT Lite package.
- [“Default Configuration” on page 1-3](#)
Shows the default configuration of the ADSP-21375 EZ-KIT Lite.
- [“Installation and Session Startup” on page 1-5](#)
Instructs how to start a new or open an existing ADSP-21375 EZ-KIT Lite session using VisualDSP++.
- [“Evaluation License Restrictions” on page 1-7](#)
Describes the restrictions of the VisualDSP++ license shipped with the EZ-KIT Lite.
- [“External Memory” on page 1-7](#)
Describes how to access external memory and defines the memory map of the EZ-KIT Lite.
- [“ELVIS Interface” on page 1-9](#)
Describes the on-board National Instruments Educational Laboratory Virtual Instrumentation Suite (NI ELVIS) interface.

Package Contents

- [“Analog Audio” on page 1-10](#).
Describes how to set up and communicate with the on-board audio codec.
- [“LEDs and Push Buttons” on page 1-11](#)
Describes the board’s general-purpose IO pins and buttons.
- [“Example Programs” on page 1-13](#)
Provides information about example programs included in the ADSP-21375 EZ-KIT Lite evaluation system.
- [“Background Telemetry Channel” on page 1-13](#)
Highlights the advantages of the Background Telemetry Channel feature of VisualDSP++.

For information on the graphical user interface, including the boot loading, target options, and other facilities of the EZ-KIT Lite system, refer to the online Help.

For detailed information on how to program the ADSP-21375 SHARC processor, refer to the documents referenced in [“Related Documents” on page xvii](#).

Package Contents

Your ADSP-21375 EZ-KIT Lite evaluation system package contains the following items.

- ADSP-21375 EZ-KIT Lite board
- *VisualDSP++ Installation Quick Reference Card*
- CD containing:
 - ✓ VisualDSP++ software
 - ✓ ADSP-21375 EZ-KIT Lite debug software

- ✓ USB driver files
 - ✓ Example programs
 - ✓ ADSP-21375 *EZ-KIT Lite Evaluation System Manual* (this document)
- Universal 7V DC power supply
 - USB 2.0 cable
 - 3.5mm stereo headphones
 - 6-foot RCA audio cable
 - 6-foot 3.5 mm/RCA x 2 Y-cable

If any item is missing, contact the vendor where you purchased your EZ-KIT Lite or contact Analog Devices, Inc.

Default Configuration

The EZ-KIT Lite evaluation system contains ESD (electrostatic discharge) sensitive devices. Electrostatic charges readily accumulate on the human body and equipment and can discharge without detection. Permanent damage may occur on devices subjected to high-energy discharges. Proper ESD precautions are recommended to avoid performance degradation or loss of functionality. Store unused EZ-KIT Lite boards in the protective shipping package.



The ADSP-21375 EZ-KIT Lite board is designed to run outside your personal computer as a stand-alone unit. You do not have to open your computer case.

When removing the EZ-KIT Lite board from the package, handle the board carefully to avoid the discharge of static electricity, which may damage some components.

Default Configuration

To connect the EZ-KIT Lite board:

1. Remove the EZ-KIT Lite board from the package. Be careful when handling the board to avoid the discharge of static electricity, which may damage some components.
2. [Figure 1-1](#) shows the default jumper settings, DIP switch, connector locations, and LEDs used in installation. Confirm that your board is set up in the default configuration before continuing.




Figure 1-1. EZ-KIT Lite Hardware Setup

3. Plug the provided power supply into J4 on the EZ-KIT Lite board. Visually verify that the green power LED (LED9) is on. Also verify that the red reset LED (LED10) goes on for a moment and then goes off, and, finally, LED1 through LED8 are sequentially blinking.
4. Connect one end of the USB cable to an available full speed USB port on your PC and the other end to ZJ1 on the ADSP-21375 EZ-KIT Lite board.

Installation and Session Startup



For correct operation, install the software and hardware in the order presented in the *VisualDSP++ Installation Quick Reference Card*.

1. Verify that the yellow USB monitor LED (ZLED3, located near the USB connector) is lit. This signifies that the board is communicating properly with the host PC and is ready to run VisualDSP++.
2. If you are running VisualDSP++ for the first time, navigate to the VisualDSP++ environment via the **Start** → **Programs** menu. The main window appears. Note that VisualDSP++ does not connect to any session. Skip the rest of this step to step 3.

If you have run VisualDSP++ previously, the last opened session appears on the screen. You can override the default behavior and force VisualDSP++ to start a new session by pressing and holding down the **Ctrl** key while starting VisualDSP++. Do not release the **Ctrl** key until the **Session Wizard** appears on the screen. Go to step 4.

Installation and Session Startup

- To connect to a new EZ-KIT Lite session, start **Session Wizard** by selecting one of the following.
 - From the **Session** menu, **New Session**.
 - From the **Session** menu, **Session List**. Then click **New Session** from the **Session List** dialog box.
 - From the **Session** menu, **Connect to Target**.
- The **Select Processor** page of the wizard appears on the screen. Ensure **SHARC** is selected in **Processor family**. In **Choose a target processor**, select **ADSP-21375**. Click **Next**.
- The **Select Connection Type** page of the wizard appears on the screen. Select **EZ-KIT Lite** and click **Next**.
- The **Select Platform** page of the wizard appears on the screen. Ensure that the selected platform is **ADSP-21375 EZ-KIT Lite via Debug Agent**. Specify your own **Session name** for your session or accept the default name.

The session name can be a string of any length; although, the box displays approximately 32 characters. The session name can include space characters. If you do not specify a session name, VisualDSP++ creates a session name by combining the name of the selected platform with the selected processor. The only way to change a session name later is to delete the session and to open a new session.

Click **Next**.

- The **Finish** page of the wizard appears on the screen. The page displays your selections. Check the selections. If you are not satisfied, click **Back** to make changes; otherwise, click **Finish**. VisualDSP++

creates the new session and connects to the EZ-KIT Lite. Once connected, the main window's title is changed to include the session name set in step 6



To disconnect from a session, click the disconnect button or select **Session**→**Disconnect from Target**.



To delete a session, select **Session** → **Session List**. Select the session name from the list and click **Delete**. Click **OK**.

Evaluation License Restrictions

The ADSP-21375 EZ-KIT Lite installation is part of the VisualDSP++ installation. The EZ-KIT Lite is a licensed product that offers an unrestricted evaluation license for the first 90 days. Once the initial unrestricted 90-day evaluation license expires:

1. VisualDSP++ allows a connection to the ADSP-21375 EZ-KIT Lite via the USB Debug Agent interface only. Connections to simulators and emulation products are no longer allowed.
2. The linker restricts a user's program to 10922 words of internal memory for code space with no restrictions for data space.

Refer to the *VisualDSP++ Installation Quick Reference Card* for details.

External Memory

The EZ-KIT Lite contains three types of memory: parallel flash (1 MB), SPI flash (2 Mbit), and SDRAM (128 Mbit). The flash memories can store user-specific boot code, allowing the board to run as a stand-alone unit. For more information about selecting the boot device for the processor, see [“Boot Mode and Clock Ratio Select Switch \(SW2\)”](#) on page 2-10.

External Memory

Table 1-1 provides start and end addresses of the board's external memories.

Table 1-1. EZ-KIT Lite Evaluation Board External Memory

Start Address	End Address	Content
0x0020 0000	0x011F 0000	SDRAM memory (~MS0)
0x0400 0000	0x040F FFFF	Flash memory (~MS1)
0x0800 0000	0x08FF FFFF	Unused chip select (~MS2) for non-SDRAM addresses
0x0800 0000	0x0BFF FFFF	Unused chip select (~MS2) for SDRAM address
0x0C00 0000	0x0CFF FFFF	Unused chip select (~MS3) for non-SDRAM addresses
0x0C00 0000	0x0FFF FFFF	Unused chip select (~MS3) for SDRAM addresses

The parallel flash memory and SDRAM connect to the external memory of the processor.

The SDRAM memory connects to the SDRAM controller of the processor. A set of programmable timing parameters is available to configure the SDRAM banks to support slower memory accesses. Care must be taken when configuring the SDRAM control registers. For more information regarding the setup of the SDRAM controller, please refer to the *ADSP-21368 SHARC Processor Hardware Reference* (includes ADSP-21375). An example program is included in the EZ-KIT Lite installation directory to demonstrate the SDRAM setup.

The SPI flash memory connects to the SPI port of the processor and designates:

- DPI pin 5 (DPI5) as a chip select
- DPI pin 3 (DPI3) as the SPI clock
- DPI pin 1 (DPI1) as the MOSI
- DPI pin 2 (DPI2) as the MISO

By default, the DPI is set up for the SPI flash, and any required changes to the SPI flash can be made by modifying the DPI of the processor. An example program is included in the EZ-KIT Lite installation directory to demonstrate the SPI flash memory reads and writes.

The parallel flash memory connects to the asynchronous memory controller of the processor. Each of their respective memory banks can be independently programmed with different timing parameters. For more information on changing wait states to speed up or slow down the asynchronous controller and other setup information, refer to the *ADSP-21368 SHARC Processor Hardware Reference* (includes ADSP-21375). Example programs are included in the EZ-KIT Lite installation directory to demonstrate the flash memory reads and writes.

ELVIS Interface

The ADSP-21375 EZ-KIT Lite board contains the National Instruments Educational Laboratory Virtual Instrumentation Suite interface. The interface features the DC voltage and current measurement modules, oscilloscope and bode analyzer modules, function generator, arbitrary waveform generator, and digital IO.

The ELVIS interface is a LabVIEW-based design and prototype environment for university science and engineering laboratories. The ELVIS interface consists of LabVIEW-based virtual instruments, a multifunction data acquisition (DAQ) device, and a custom-designed bench-top workstation and prototype board. This combination provides a ready-to-use suite of instruments found in most educational laboratories. Because the interface is based on LabVIEW and provides complete data acquisition and prototyping capabilities, the system is ideal for academic coursework that range from lower-division classes to advanced project-based curriculums.

For more information on ELVIS and example demonstration programs, visit National Instruments Web site at www.ni.com.

Analog Audio

The AD1835A is a high-performance, single-chip codec featuring four stereo digital-to-analog converters (DACs) for audio output and one stereo analog-to-digital converters (ADCs) for audio input. The codec can input and output data with a sample rate of up to 96 kHz on all channels. A 192 kHz sample rate can be used with one of the DAC channels.

The processor is interfaced with the AD1835A via the DAI port. The DAI interface pins can be configured to transfer serial data from the AD1835A codec in either time-division multiplexed (TDM) or two-wire interface mode (TWI). For more information on the AD1835A connection to the DAI, see [“DAI Interface” on page 2-4](#).

The master input clock (MCLK) for the AD1835A device can be generated by the on-board 12.288 MHz oscillator or can be supplied by one of the DAI pins of the processor. Using one of the pins to generate the MCLK, as opposed to the on-board oscillator, allows synchronization of multiple devices in the system. It is possible to disable the on-board audio oscillator from driving the audio codec and the processor’s input pin. For instructions on how to configure the clock, refer to [“Codec Setup Switch \(SW3\)” on page 2-11](#).

The AD1835A codec can be configured as a master or as a slave, depending on the DIP switch settings. In master mode, the AD1835A drives the serial port clock and frame sync signals to the processor. In slave mode, the processor must generate and drive all of the serial port clock and frame sync signals. For information on how to set up the mode, refer to [“Codec Setup Switch \(SW3\)” on page 2-11](#).

The internal configuration registers of the AD1835A codec are configured using the SPI port of the processor. The DPI pin 4 (DPI4 register) is used as the select for the device. For information on how to configure the multichannel codec, refer to the product datasheet at

<http://www.analog.com/en/prod/0,2877,AD1835A,00.html>.

The RCA connector (J10) is used to input analog audio. When using an electret microphone on this connector, configure the SW4 switch according to the instructions in [“Electret Microphone Select Switch \(SW4\)” on page 2-12](#). The four output channels connect to the RCA connector J5. Channel 4 of the codec connects to the headphone jack J9. For more information about the connectors see [“Connectors” on page 2-21](#).

Example programs are included in the EZ-KIT Lite installation directory to demonstrate how to configure and use the board’s analog audio interface.

LEDs and Push Buttons

The EZ-KIT Lite has eight general-purpose user LEDs and four general-purpose push buttons.

Two of the general-purpose push buttons are attached to the FLAG pins of the processor, while the other two are attached to the DAI pins. All of the push buttons connect to the processor through a DIP switch. The DIP switch allows processor pins, which connect to the push buttons, to be disconnected. See [“Push Button Enable Switch \(SW7\)” on page 2-13](#) for instructions on how to disable a push button from driving its corresponding processor pin.

The state of the push buttons, connected to the FLAG pins, can be determined by reading the FLAG register. The push buttons connected to the DAI pins must be configured as interrupts. It is necessary to set up an interrupt routine to determine each pin’s state. [Table 1-2](#) shows the push button and processor connections. Refer to the related example program shipped with the EZ-KIT Lite for more information.

LEDs and Push Buttons

Table 1-2. Push Button Connections

Push Button Label	Push Button Reference Designator	Processor Pin
PB1	SW8	FLAG1/~IRQ1
PB2	SW11	FLAG0/~IRQ0
PB3	SW10	DAI19
PB4	SW9	DAI20

[Table 1-3](#) summarizes the LED connections to the processor. To use the LEDs connected to the DAI or DPI, configure the respective registers of the processor. For more information, refer to the *ADSP-21368 SHARC Processor Hardware Reference* (includes ADSP-21375).

Table 1-3. LED Connections

LED Reference Designator	Processor Pin
LED1	DPI6
LED2	DPI7
LED3	DPI8
LED4	DPI13
LED5	DPI14
LED6	DAI15
LED7	DAI16
LED8	FLAG3/~MS3/~IRQ3



An example program is included in the EZ-KIT Lite installation directory to demonstrate the functionality of the LEDs and push buttons.

Example Programs

Example programs are provided with the ADSP-21375 EZ-KIT Lite to demonstrate various capabilities of the evaluation board. These programs are installed with the EZ-KIT Lite software in the ...\`213xx`\Examples\ADSP-21375 EZ-KIT Lite subdirectory of the VisualDSP++ installation directory. Please refer to the readme file provided with each example for more information.

Background Telemetry Channel

The ADSP-21375 USB debug agent supports the background telemetry channel (BTC), which facilitates data exchange between VisualDSP++ and the processor without interrupting processor execution.

The BTC allows you to view a variable as it is updated or changed, all while the processor continues to execute. For increased performance of the BTC, including faster reading and writing, please check our latest line of SHARC processor emulators at <http://www.analog.com/processors/sharc/evaluationDevelopment/crosscore/index.html>. For more information about the background telemetry channel, see the *VisualDSP++ User's Guide* or online Help.

Background Telemetry Channel

2 ADSP-21375 EZ-KIT LITE HARDWARE REFERENCE

This chapter describes the hardware design of the ADSP-21375 EZ-KIT Lite board. The following topics are covered.

- [“System Architecture” on page 2-2](#)
Describes the configuration of the ADSP-21375 board and explains how the board components interface with the processor.
- [“Switch Settings” on page 2-9](#)
Shows the location and describes the function of the board switches.
- [“LEDs and Push Buttons” on page 2-15](#)
Shows the location and describes the function of the board LEDs and push buttons.
- [“Jumpers” on page 2-18](#)
Shows the location and describes the function of the board jumpers.
- [“Connectors” on page 2-21](#)
Shows the location and gives the part number for all of the connectors on the board. Also, the manufacturer and part number information is given for the mating parts.

System Architecture

This section describes the processor's configuration on the EZ-KIT Lite board (Figure 2-1).




Figure 2-1. System Architecture Block Diagram

This EZ-KIT Lite has been designed to demonstrate the capabilities of the ADSP-21375 processor. The processor core is powered at 1.2V, and the IO is powered at 3.3V.

The CLKIN pin of the processor connects to a 16.384 MHz oscillator. The core frequency of the processor is derived by multiplying the frequency at the CLKIN pin by a value determined by the state of the processor pins CLKCFG1 and CLKCFG0. The value at these pins is determined by the state of the SW2 switch (see [“Boot Mode and Clock Ratio Select Switch \(SW2\)” on page 2-10](#)). By default, the EZ-KIT Lite gives a core frequency of 262.144 MHz. It is possible to change the speed of the processor by changing the value of the PMCTL register.

The SW2 switch also configures the boot mode of the processor. The EZ-KIT Lite is capable of EPROM/flash boot and SPI boot. By default, the EZ-KIT Lite boots from the flash memory. For information about configuring the boot modes, see [“Boot Mode and Clock Ratio Select Switch \(SW2\)” on page 2-10](#).

External Port

The external port of the ADSP-21375 processor consists of a 24-bit address bus, 16-bit data memory bus, and control lines. The control lines are used to select, read, and write to external memory devices.

The external port connects to an 8-bit parallel flash memory and a 16-bit SDRAM memory. See [“External Memory” on page 1-7](#) for more information about accessing the flash and SDRAM memories.

All of the external port signals are available externally via the expansion interface connectors (J1-3). The pinout of the connectors can be found in [“ADSP-21375 EZ-KIT Lite Schematic” on page B-1](#).

DAI Interface

The digital application interface (DAI) pins connect to the signal routing unit (SRU) of the processor. The SRU is a flexible routing system, providing a large system of signal flows within the processor. In general, the SRU allows to route the DAI pins to different internal peripherals in various combinations.

The DAI pins connect to the AD1835A audio codec, a 26-pin header, two RCA connectors, audio oscillator output, an external phase lock loop (PLL) circuit, two LEDs, and two push buttons. [Figure 2-2](#) illustrates the EZ-KIT Lite's connections to the DAI.




Figure 2-2. DAI Connections Block Diagram

To use the DAI for a different purpose, disable any signal driving the DAI pin with a switch (see “[Codec Setup Switch \(SW3\)](#)” on page 2-11). In addition, the SW3 switch allows flexible routing of the 12.288 MHz audio oscillator’s output signal. By default, this signal is used as the master clock (MCLK) for the AD1835A codec.

All of the DAI signals are available externally via the expansion interface connectors (J1-3), as well as the 0.1” spaced header P4. The pinout of the connectors can be found in “[ADSP-21375 EZ-KIT Lite Schematic](#)” on page B-1.

DPI Interface

The digital peripheral interface (DPI) pins connect to a second signal routing unit of the processor (SRU2). The SRU2 unit, similar to the SRU, is a flexible routing system, providing a large system of signal flows within the processor. In general, the SRU2 allows to route the DPI pins to different internal peripherals in various combinations.




Figure 2-3. DPI Connections Block Diagram

System Architecture

The DPI pins connect to the SPI flash memory, the SPI interface of the AD1835A codec, a UART, a 20-pin header, and five LEDs. [Figure 2-3](#) illustrates the EZ-KIT Lite's connections to the DPI.

To use the DPI for a different purpose, disable any signal driving the DPI pins with a switch (see [“UART Enable Switch \(SW5\)”](#) on page 2-12). Any DPI pin connected to a LED can be used without having to disconnect the pin. You can, however, see the respective LED turn ON and OFF when using the signal elsewhere on the board.

All of the DPI signals are available externally via the expansion interface connectors (J1-3), as well as the 0.1” spaced header P3. The pinout of these connectors can be found in [“ADSP-21375 EZ-KIT Lite Schematic”](#) on page B-1.

FLAG Pins

The processor has four general-purpose IO flag pins. [Table 2-1](#) describes the flag connections.

Table 2-1. IO FLAG Pins

FLAG Pin	EZ-KIT Lite Function
FLAG0	Push button (SW2) input
FLAG1	Push button (SW2) input
FLAG2	SDRAM chip select
FLAG3	LED8

For information on how to disable a push button from driving its corresponding processor flag pin, see [“Push Button Enable Switch \(SW7\)”](#) on page 2-13.

The FLAG signals are available externally via the expansion interface connectors (J1-3). The pinout of these connectors can be found in [“ADSP-21375 EZ-KIT Lite Schematic” on page B-1](#).

External PLL

The ADSP-21375 EZ-KIT Lite contains an external phase lock loop to help generate a faster and more stable master input clock MCLK. The PLL uses DAI pin 3 as an input clock from the ADSP-21375 processor. The new clock generated by PLL connects to the processor via DAI pin 2.

Example programs are included in the EZ-KIT Lite installation directory to demonstrate how to configure and use the board’s external PLL.

Expansion Interface

The expansion interface consists of the three 90-pin connectors. [Table 2-2](#) shows the interfaces each connector provides. For the exact pinout of the connectors, refer to [“ADSP-21375 EZ-KIT Lite Schematic” on page B-1](#). The mechanical dimensions of the connectors can be obtained from [Technical or Customer Support](#).

Table 2-2. Expansion Interface Connectors

Connector	Interfaces
J1	5V, ADDR23-0, DATA31-0
J2	3.3V, FLAG3-0, DAIP20-1, DPI14-1, SDRAM control signals
J3	5V, 3.3V, reset, parallel port control signals

System Architecture

Limits to the current and to the interface speed must be taken into consideration when using the expansion interface. The maximum current limit is dependent on the capabilities of the used regulator. Additional circuitry also can add extra loading to signals, decreasing their maximum effective speed.



Analog Devices does not support and is not responsible for the effects of additional circuitry.

JTAG Emulation Port

The JTAG emulation port allows an emulator to access the internal and external memory of the processor through a 6-pin interface. The JTAG emulation port of the processor also connects to the USB debugging interface. When an emulator connects to the board at ZP4, the USB debugging interface is disabled. This is not a standard connection of the JTAG interface.

For information about the standard connection of the interface, see *EE-68* published on the Analog Devices Web site. For more information about the JTAG connector, see “[JTAG Header \(ZP4\)](#)” on page 2-25. To learn more about available SHARC processor emulators, go to <http://www.analog.com/processors/sharc/evaluationDevelopment/crosscore/index.html>.

Switch Settings

This section describes the function of the EZ-KIT Lite switches.

Figure 2-4 shows the switch locations and default settings.




Figure 2-4. Switch Locations and Default Settings

Switch Settings

Boot Mode and Clock Ratio Select Switch (SW2)

The SW2 switch sets the boot mode and clock multiplier ratio. [Table 2-3](#) shows how to set up the boot mode using SW2 positions 1 and 2. By default, the EZ-KIT Lite boots in external port mode from the flash memory.

Table 2-3. Boot Mode Configuration Switch (SW2)

BOOTCFG0 Pin (Position 1)	BOOTCFG1 Pin (Position 2)	Boot Mode
ON	ON	SPI slave boot
ON	OFF	Parallel flash boot (default)
OFF	ON	SPI master boot
OFF	OFF	Reserved

[Table 2-4](#) shows how to set up the clock multiply ratio using SW2 positions 3 and 4. By default, the processor increases the clock multiply ratio by sixteen, setting the core clock to 262.144 MHz.

Table 2-4. Core Clock Rate Configuration

CLKCFG0 (Position 3)	CLKCFG1 (Position 4)	Core to CLKIN Ratio
ON	ON	6:1
ON	OFF	16:1 (default)
OFF	ON	32:1
OFF	OFF	Reserved

The core clock frequency can be increased or decreased via software by writing to the PMCTL register. For more information on changing the core clock frequency and other setup information, refer to the *ADSP-21368 SHARC Processor Hardware Reference* (includes ADSP-21375).

Codec Setup Switch (SW3)

The codec setup switch (SW3) can be used to change the routing of some signals going to the AD1835A codec and to set up the communication protocol of the codec.

SW3 positions 1 and 2 determine the clock routing for the audio oscillator to the codec and to the processor. [Figure 2-5](#) illustrates how the switch positions 1 and 2 connect on the board. In the default position, route the DAI_P17 pin to DAI_P6 (in software) to clock the AD1835A codec.




Figure 2-5. Audio Clock Routing

SW3 position 3 determines if the AD1835A device is a master or a slave. If the AD1835A is a master, the device's serial interface generates the frame sync and clock signals necessary to transfer data. When the device is a slave, the processor must generate the frame sync and clock signals. By default, position 3 is ON, and the AD1835A codec generates the control signals.

SW3 position 4 disconnects the AD1835A codec's ADC_DATA pin from the DAI interface. This is useful when the DAI interface connects to another device.

Switch Settings

Electret Microphone Select Switch (SW4)

To connect an electret microphone to the audio input, place all positions of the SW4 switch ON. The default position of the switch is all OFF. When all of the SW4 positions are ON, a DC offset of 2.5V is added to the signal, and gain of the input amplifiers is changed from 1x to 10x.

UART Enable Switch (SW5)

The UART enable switch (SW5) disconnects UART signals from the DPI pins of the processor. When the switch is OFF, the associated DPI signal (see [Table 2-5](#)) can be used on the expansion interface.

Table 2-5. UART Enable Switch (SW5)

Switch Position	EZ-KIT Lite Signal	Processor Signal
1 (OFF ¹)	CTS	DPI12
2 (ON)	RX	DPI10
3 (OFF)	RTS	DPI11
4 (ON)	T2IN tied to R2OUT	N/A

1 Bold typeface denotes the default setting.

Loop-Back Test Switches (SW6 and SW14)

The loop-back test switch SW6 is located at the top left side of the board. The second loop-back test switch, SW14, is located at the top right side of the board. These switches are used only for testing; all switch positions should remain OFF.

Push Button Enable Switch (SW7)

The push button enable switch (SW7) disconnects the push buttons from the corresponding processor pins. This allows the signals to be used elsewhere on the board. [Table 2-6](#) shows the SW7 connections. By default, all position of the SW7 switch are ON, allowing the push buttons to function as designed.

Table 2-6. Push Button Enable Switch (SW7)

Switch Position	Push Button Label	Push Button Reference Designator	Processor Pin
1	PB1	SW8	FLAG1/~IRQ
2	PB2	SW11	FLAG0/~IRQ0
3	PB3	SW10	DAI19
4	PB4	SW9	DAI20

ELVIS Oscilloscope Configuration Switch (SW1)

The oscilloscope configuration switch (SW1) determines which audio circuit signals connect to channels A and B of the oscilloscope. The switch is used only when the board connects to the Educational Laboratory Virtual Instrumentation Suite (ELVIS) station (see [“ELVIS Interface” on page 1-9](#)). Each channel must have only one signal selected at a time, as described in [Table 2-7](#).

Table 2-7. Oscilloscope Configuration Switch (SW1)

Channel	Switch Position	Audio Circuit Signal
A	1 (OFF ¹)	AMP_LEFT_IN
A	2 (OFF)	AMP_RIGHT_IN
A	3 (OFF)	LEFT_OUT
A	4 (OFF)	RIGHT_OUT
B	5 (OFF)	AMP_LEFT_IN

Switch Settings

Table 2-7. Oscilloscope Configuration Switch (SW1) (Cont'd)

Channel	Switch Position	Audio Circuit Signal
B	6 (OFF)	AMP_RIGHT_IN
B	7 (OFF)	LEFT_OUT
B	8 (OFF)	RIGHT_OUT

1 Bold typeface denotes the default settings.

ELVIS Function Generator Configuration Switch (SW13)

The function generator configuration switch (SW13) controls which signals connect to the left and right input signals of the audio interface. The SW13 switch is used only when the board connects to the ELVIS station (see “[ELVIS Interface](#)” on page 1-9). Each channel must have only one signal selected at a time, as described in [Table 2-8](#).

Table 2-8. ELVIS Function Generator Configuration Switch (SW13)

Channel	Switch Position	Audio Signal
AMP_LEFT_IN	1 (ON ¹)	LEFT_IN
AMP_RIGHT_IN	2 (ON)	RIGHT_IN
AMP_LEFT_IN	3 (OFF)	DAC0
AMP_RIGHT_IN	4 (OFF)	DAC1
AMP_LEFT_IN	5 (OFF)	FUNCT_OUT
AMP_RIGHT_IN	6 (OFF)	FUNCT_OUT

1 Bold typeface denotes the default settings.

AD1835A and Flash Disconnect Switch (SW15)

The AD1835A and flash disconnect switch (SW15) disconnects the following signals: DPI4_SPI_AD1835_CS, DAIP8_ADC_LRCLK, and DPI5_SPI_FLASH_CS. The switch is used only for expansion interface purposes; by default, the switch positions 1–3 are ON and position 4 is OFF.

LEDs and Push Buttons

This section describes the functionality of the LEDs and push buttons. [Figure 2-6](#) shows the LED and push button locations.




Figure 2-6. LED and Push Button Locations

General Purpose LEDs (LED1–8)

There are eight general-purpose LEDs on the board. Five LEDs connect to the DPI interface, two LEDs connect to the DAI interface, and one LED connects to `FLAG3` of the processor. “LEDs and Push Buttons” on [page 1-11](#) summarizes the LED connections. The respective registers of the processor must be programmed appropriately in order to use LEDs connected to the DAI or DPI. For more information on how to program the registers, refer to the *ADSP-21368 SHARC Processor Hardware Reference* (includes ADSP-21375).

Power LED (LED9)

When LED9 is lit (green), it indicates that power is being supplied to the board properly.

Reset LED (LED10)

When LED10 is lit (red), the master reset of all the major ICs is active.

USB Monitor LED (ZLED3)

The USB monitor LED (ZLED3) indicates that USB communication has been initialized successfully, and you can connect to the processor using a VisualDSP++ EZ-KIT Lite session. Once the USB cable is plugged into the board, it takes approximately 15 seconds for the USB monitor LED to light. If the LED does not light, try cycling power on the board and/or reinstalling the USB driver (see the *VisualDSP++ Installation Quick Reference Card*).



When VisualDSP++ is actively communicating with the EZ-KIT Lite target board, the LED can flicker, indicating communications handshake.

Push Buttons (SW8–11)

Four push buttons (SW8-11) are provided for general-purpose user input: two push buttons connect to the FLAG pins of the processor, while the other two connect to the DAI of the processor. The push buttons are active high and, when pressed, send a high (1) to the processor. Refer to [“LEDs and Push Buttons” on page 1-11](#) for more information. The push button enable switch (SW7) is capable of disconnecting the push buttons from the corresponding processor pins (refer to [“Push Button Enable Switch \(SW7\)” on page 2-13](#) for more information).

The push buttons and corresponding processor signals are summarized in [Table 2-9](#).

Table 2-9. Push Button Connections

Push Button Label	Push Button Reference Designator	Processor Pin
PB1	SW8	FLAG1/~IRQ1
PB2	SW11	FLAG0/~IRQ0
PB3	SW10	DAI19
PB4	SW9	DAI20

Board Reset Push Button (SW12)

The RESET push button (SW12) resets all of the ICs on the board. The only exception is the USB interface chips. These chips are not being reset when the push button is pressed after the USB cable has been plugged in and communication correctly initialized with the PC. After USB communication has been initialized, the only way to reset the USB is by powering down the board.

Jumpers

Figure 2-7 shows the locations and default settings of the EZ-KIT Lite jumpers.




Figure 2-7. Jumper Locations

VCO Select Jumper (JP1)

The voltage-controlled oscillator (VCO) select jumper (JP1) configures the frequency selection of the on-board external PLL (U39). When JP1 is installed, the VCO output frequency is multiplied by a factor of 1.0. Conversely, when uninstalled, the VCO output frequency is multiplied by a factor of 0.5 or divided in half. The jumper settings are shown in [Table 2-10](#).

Table 2-10. VCO Select Jumper (JP1)

JP1 Setting	Mode
OFF	VCO output frequency x ½ (default)
ON	VCO output frequency x 1.0

ELVIS Select Jumper (JP2)

The ELVIS select jumper (JP2) configures the EZ-KIT Lite's connection to an ELVIS station (see [“ELVIS Interface” on page 1-9](#)). When JP2 is installed, the connections to the push buttons and LED are re-directed to the ELVIS station instead of the processor. The jumper settings are shown in [Table 2-11](#).

Table 2-11. ELVIS Select Jumper (JP2)


JP2 Setting	Mode
OFF	Not connected to an ELVIS station (default)
ON	Connected to an ELVIS station

ELVIS Voltage Selection Jumper (JP3)

The ELVIS voltage selection jumper (JP3) is used to select the power source for the EZ-KIT Lite. In a standard mode of operation, the board receives its power from an external power supply. When JP3 is installed, the board is powered from an ELVIS station and no external power supply is required. The jumper settings are shown in [Table 2-12](#).

Table 2-12. ELVIS Voltage Selection Jumper (JP3)

JP3 Setting	Mode
OFF	Powered from an external power supply (default)
ON	Powered from an ELVIS station

-  The external power supply must be disconnected from the board when JP3 is installed to avoid potential damage to the EZ-KIT Lite board and ELVIS unit.

ELVIS Programmable Flag Jumper (JP4)

The ELVIS programmable flag jumper (JP4) connects the ADSP-21375 processor's DAI4 pin to the ELVIS trigger pin. When JP4 is installed, DAI4 connects to the ELVIS TRIG1_2 pin directly. Conversely, when JP4 is uninstalled, the DAI4 pin is disconnected and can be used for another non-ELVIS operation. The jumper settings are shown in [Table 2-13](#).

Table 2-13. ELVIS Select Jumper (JP4)

JP4 Setting	Mode
OFF	DAI4 disconnected from the ELVIS TRIG pin (default)
ON	DAI4 connected to the ELVIS TRIG pin

Connectors

This section describes the connector functionality and provides information about mating connectors. [Figure 2-8](#) shows the connector locations.




Figure 2-8. Connector Locations

Connectors

Expansion Interface Connectors (J1-3)

Three board-to-board connectors (J1-3) provide signals for most of the processor's peripheral interfaces. The connectors are located at the bottom of the board. For more information about the expansion interface, see [“Expansion Interface” on page 2-7](#). For the J1-3 connectors' availability and pricing, contact Samtec.

Part Description	Manufacturer	Part Number
90-position 0.05" spacing, SMT	SAMTEC	SFC-145-T2-F-D-A
Mating Connectors		
90-position 0.05" spacing (through hole)	SAMTEC	TFM-145-x1 series
90-position 0.05" spacing (surface mount)	SAMTEC	TFM-145-x2 series
90-position 0.05" spacing (low cost)	SAMTEC	TFC-145 series

Audio In RCA Connector (J10)

Part Description	Manufacturer	Part Number
Two-channel right angle RCA jack	SWITCHCRAFT	PJRS1X2S02
Mating Cable		
Two-channel RCA interconnect cable	MONSTER CABLE	BI100-1M

Audio Out RCA Connector (J5)

Part Description	Manufacturer	Part Number
Four-channel right angle RCA jack	SWITCHCRAFT	PJRS4X2U01

Part Description	Manufacturer	Part Number
Mating Cable		
Two-channel RCA interconnect cable	MONSTER CABLE	BI100-1M

Headphone Out Jack (J9)

Part Description	Manufacturer	Part Number
3.5 mm stereo jack	A/D ELECTRONICS	ST-323-5

Power Jack (J4)

The power connector (J4) provides all of the power necessary to operate the EZ-KIT Lite board.

Part Description	Manufacturer	Part Number
2.5 mm power jack	SWITCHCRAFT DIGI-KEY	RAPC712X-ND
Mating Power Supply (shipped with EZ-KIT Lite)		
7V power supply	CUI INC.	DMS070214-P6P-SZ

The power connector supplies DC power to the EZ-KIT Lite board. [Table 2-14](#) shows the power supply specifications.

Table 2-14. Power Supply Specifications

Terminal	Connection
Center pin	+7 VDC@2.14A
Outer ring	GND

Connectors

S/PDIF Coax Connectors (J7 and J8)

Part Description	Manufacturer	Part Number
Coaxial	SWITCHCRAFT	PJ1RAN1X1U01
Mating Cable		
Two-channel RCA interconnect cable	MONSTER CABLE	BI100-1M

DPI Header (P3)

The DPI connector (P3) provides access to all of the DPI signals in the form of a .1" spacing header. When using the header to access the DPI pins of the processor, ensure that signals, which normally drive the DPI pins, are disabled. For more information, see [“DPI Interface” on page 2-5](#).

Part Description	Manufacturer	Part Number
20-pin IDC header	FCI	68737-420HLF



DAI Header (P4)

The DAI connector (P4) provides access to all of the DAI signals in the form of a .1" spacing header. When using the header to access the DAI pins of the processor, ensure that signals, which normally drive the DAI pins, are disabled. Refer to [“Codec Setup Switch \(SW3\)” on page 2-11](#) for more information on how to disable signals already being driven from elsewhere on the EZ-KIT Lite.

Part Description	Manufacturer	Part Number
26-pin IDC header	BERG	4102-T08-13LF

JTAG Header (ZP4)

The JTAG header (ZP4) is the connecting point for a JTAG in-circuit emulator pod. When an emulator connects to the JTAG header, the USB debug interface is disabled.

-  Pin 3 is missing to provide keying. Pin 3 in the mating connector should have a plug.
-  When using an emulator with the EZ-KIT Lite board, follow the connection instructions provided with the emulator.

Part Description	Manufacturer	Part Number
14-pin IDC header	FCI	68737-414HLF

Connectors

A ADSP-21375 EZ-KIT LITE BILL OF MATERIALS

The bill of materials corresponds to “[ADSP-21375 EZ-KIT Lite Schematic](#)” on page B-1.

Ref.	Qty.	Description	Reference Designator	Manufacturer	Part Number
1	1	74LVC14A SOIC14	U40	TI	74LVC14AD
2	1	IDT74FCT3244 APY SSOP20	U37	IDT	IDT74FCT3244APYG
3	1	12.288MHZ OSC003	U1	DIGI-KEY	SG-8002CA-PCC-ND (12.288M)
4	1	LT1765 SOIC8	VR1	LINEAR TECH	LT1765ES8#PBF
5	1	GTL2002 TSSOP8	U39	PHILIPS	GTL2002DP-T
6	1	LTC1877 MSOP8	VR2	LINEAR TECH	LTC1877EMS8#PBF
7	3	SN74LVC1G08 SOT23-5	U16-18	TI	SN74LVC1G08DBVR
8	1	TLC2932 TSSOP14	U38	TI	TLC2932IPWG4
9	1	16.384MHZ OSC003	U28	EPSON	SG-8002CA-MPT
10	1	MT48LC8M16A 2P-6A TSOP54	U7	MICRON	MT48LC8M16A2P-6A
11	1	21375 M25P20 “U29”	U29	ST MICRO	M25P20-VMN6TP

Ref.	Qty.	Description	Reference Designator	Manufacturer	Part Number
12	1	21375 AM29LV081B "U35"	U35	AMD	AM29LV081-120ED
13	1	FDC658P SOT23-6	U3	FAIRCHILD	FDC658P
14	1	ADM708SARZ SOIC8	U23	ANALOG DEVICES	ADM708SARZ
15	1	AD8532ARZ SOIC8	U19	ANALOG DEVICES	AD8532ARZ
16	2	ADP3336ARMZ MSOP8	VR3-4	ANALOG DEVICES	ADP3336ARMZ-REEL
17	1	ADM3202ARNZ SOIC16	U32	ANALOG DEVICES	ADM3202ARNZ
18	8	AD8606ARZ SOIC8	U8-15	ANALOG DEVICES	AD8606ARZ
19	1	AD1835AASZ MQFP52	U31	ANALOG DEVICES	AD1835AASZ
20	2	AD623ARMZ USOIC8	U5-6	ANALOG DEVICES	AD623ARMZ
21	2	AD820ARZ SOIC8	U33-34	ANALOG DEVICES	AD820ARZ
22	1	ADSP-21375KS Z MQFP208	U44	ANALOG DEVICES	ADSP-21375KSZ-ENG
23	2	ADG774ABRQZ QSOP16	U24-25	ANALOG DEVICES	ADG774ABRQZ
24	1	ADP1864 SOT23-6	VR5	ANALOG DEVICES	ADP1864AUJZ-R7
25	5	RUBBERFOOT	M1-5	MOUSER	517-SJ-5018BK
26	1	PWR 2.5MM_JACK CON005	J4	SWITCHCRAFT	RAPC712X

ADSP-21375 EZ-KIT Lite Bill Of Materials

Ref.	Qty.	Description	Reference Designator	Manufacturer	Part Number
27	1	RCA 4X2 CON011	J5	SWITCHCRAFT	PJRS4X2U01X
28	5	MOMENTARY SWT013	SW8-12	PANASONIC	EVQ-PAD04M
29	3	.05 45X2 CON019	J1-3	SAMTEC	SFC-145-T2-F-D-A
30	2	DIP8SWT016	SW1,SW14	C&K	TDA08H0SB1
31	1	DIP6SWT017	SW13	CTS	218-6LPST
32	7	DIP4SWT018	SW2-7,SW15	ITT	TDA04HOSB1
33	1	DB99PINDB9F	J6	AMP/TYCO	5745781-4
34	1	RCA RCA_1X2 CON031	J10	SWITCHCRAFT	PJRS1X2S02X
35	4	IDC 2X1 IDC2X1	JP1-4	FCI	90726-402HLF
36	1	IDC 7X2 IDC7X2	ZP4	FCI	68737-414HLF
37	1	IDC 10X2 IDC10X2	P3	FCI	68737-420HLF
38	1	2.5A RESETABLE FUS001	F1	RAYCHEM	SMD250F-2
39	1	IDC 2X2 IDC2X2	P11	FCI	68737-404HLF
40	1	3.5MM STEREO_JACK CON001	J9	A/D ELEC- TRONICS	ST-323-5
41	1	IDC 13x2 IDC13x2	P4	BERG	54102-T08-13LF
42	8	YELLOW LED001	LED1-8	PANASONIC	LN1461C

Ref.	Qty.	Description	Reference Designator	Manufacturer	Part Number
43	10	0.22UF 25V 10% 0805	C77,C91-92,C118-119,C152-154, C185-186	AVX	08053C224FAT
44	2	0.1UF 50V 10% 0805	C172,C216	AVX	08055C104KAT
45	1	220PF 50V 10% 1206	C224	AVX	12061A221JAT2A
46	4	600 100MHZ 200MA 0603	FER2-5	DIGI-KEY	490-1014-2-ND
47	2	2A S2A DO-214AA	D3-4	MICRO COMM	S2A-TP
48	1	4A SSB43L DO-214AA	D5	VISHAY	SSB43L
49	4	1UF 16V 10% 0805	C204,C207-209	PANASONIC	ECJ2FB1E105K
50	1	249.0K 1/10W 1% 0805	R189	VISHAY	CRCW0805249KFKE A
51	1	124.0K 1/10W 1% 0805	R188	VISHAY	CRCW0805-124KFKE A
52	2	10UF 25V +80-20% 1210	C215,C221	PANASONIC	ECJ4YF1E106Z
53	2	68UF 25V 20% CAP003	CT1-2	PANASONIC	EEE-FC1E680P
54	1	2A SL22 DO-214AA	D1	DIGI-KEY	SL22-E3/1GI-ND
55	1	10UH 20% IND001	L1	TDK	445-2014-1-ND
56	2	0 1/10W 5% 0805	R195-196	VISHAY	CRCW08050000Z0EA
57	1	190 100MHZ 5A FER002	FER7	MURATA	DLW5BSN191SQ2

ADSP-21375 EZ-KIT Lite Bill Of Materials

Ref.	Qty.	Description	Reference Designator	Manufacturer	Part Number
58	21	10UF 6.3V 10% 0805	C23-24,C57-58, C84-85,C111-114, C144-147,C151, C162-163,C176, C205-206,C223	AVX	080560106KAT2A
59	3	6.04K 1/10W 1% 0805	R28-30	DIGI-KEY	311-6.04KCRCT-ND
60	6	0.1UF 10V 10% 0402	C75-76,C168-171	AVX	0402ZD104KAT2A
61	93	0.01UF 16V 10% 0402	C1,C4,C6-22,C25-56,C59-65,C68-74, C78-83,C86-87, C90,C93,C100, C173-175, C177-178, C183-184,C188, C190-196, C201-202	AVX	0402YC103KAT2A
62	25	10K 1/16W 5% 0402	R5,R9-10,R19-26, R32-34,R132, R152-156, R161-162, R173-175	VISHAY	CRCW040210K0FKE D
63	2	4.7K 1/16W 5% 0402	R1,R180	VISHAY	CRCW04024K70JNE D
64	13	0 1/16W 5% 0402	R2-4,R7-8,R11-15, R107,R121,R138	PANASONIC	ERJ-2GE0R00X
65	2	22 1/16W 5% 0402	R124,R133	PANASONIC	ERJ-2GEJ220X
66	2	33 1/16W 5% 0402	R6,R27	VISHAY	CRCW040233R0JNEA
67	1	1.5UH 20% IND003	L2	COIL CRAFT	DO1608C-152MLC

Ref.	Qty.	Description	Reference Designator	Manufacturer	Part Number
68	1	100MA CMD5H-3 SOD-323	D2	CENTRAL SEMI	CMD5H-3-E3
69	1	47UF 16V 10% D	CT4	DIGI-KEY	478-1788-2-ND
70	1	0.18UF 25V 10% 0805	C218	AVX	08053C184KAT2A
71	1	100UF 10V 10% C	CT3	KOA	TMC1ACTTE107K
72	2	1000PF 50V 5% 0402	C213-214	AVX	04025C102JAT2A
73	2	64.9K 1/10W 1% 0805	R190,R194	VISHAY	CRCW080564K9FKE A
74	2	210.0K 1/4W 1% 0805	R191,R193	VISHAY	CRCW0805210KFKE A
75	2	0.1UF 16V 10% 0603	C187,C189	AVX	0603YC104KAT2A
76	1	1UF 16V 10% 0603	C179	PANASONIC	ECJ-1VB1C105K
77	2	4.7UF 25V 20% 0805	C217,C220	AVX	0805ZD475KAT2A
78	1	68PF 50V 5% 0603	C2	AVX	06035A680JAT2A
79	8	330PF 50V 5% 0603	C95,C101,C107, C116,C123,C129, C134,C142	AVX	06035A331JAT2A
80	1	470PF 50V 5% 0603	C5	AVX	06033A471JAT2A
81	11	330 1/10W 5% 0603	R139,R163-164, R168-172, R176-178	VISHAY	CRCW0603330RJNEA

ADSP-21375 EZ-KIT Lite Bill Of Materials

Ref.	Qty.	Description	Reference Designator	Manufacturer	Part Number
82	8	0 1/10W 5% 0603	R18,R31,R126, R184-187,R192	PHYCOMP	232270296001L
83	4	10 1/10W 5% 0603	R157-160	VISHAY	CRCW060310R0JNEA
84	3	10.0K 1/16W 1% 0603	R125,R142,R148	DALE	CRCW060310K0FKE A
85	1	75.0K 1/16W 1% 0603	R131	VISHAY	CRCW060375K0FKE A
86	1	200.0K 1/16W 1% 0603	R134	VISHAY	CRCW0603200KFKE A
87	1	25.5K 1/16W 1% 0603	R150	DIGI-KEY	311-25.5KHRTR-ND
88	4	237.0 1/10W 1% 0603	R108-109, R122-123	DIGI-KEY	311-237HRTR-ND
89	2	750.0K 1/10W 1% 0603	R110,R116	DIGI-KEY	311-750KHRTR-ND
90	11	11.0K 1/10W 1% 0603	R39-40,R50,R58, R73,R81,R86,R97, R102,R115,R144	DIGI-KEY	311-11.0KHRTR-ND
91	20	5.49K 1/10W 1% 0603	R37,R41-42,R48, R51,R56,R59,R67, R72,R75,R80, R83-84,R87,R96, R99,R103-104, R113-114	DIGI-KEY	311-5.49KHRTR-ND
92	9	3.32K 1/10W 1% 0603	R36,R43,R49,R57, R74,R82,R85,R94, R130	DIGI-KEY	311-3.32KHRTR-ND
93	8	1.65K 1/10W 1% 0603	R44,R52,R60,R64, R71,R79,R88,R95	DIGI-KEY	311-1.65KHRTR-ND
94	10	49.9K 1/10W 1% 0603	R46,R55,R63,R66, R68,R76,R91-92, R119-120	DIGI-KEY	311-49.9KHRTR-ND


Ref.	Qty.	Description	Reference Designator	Manufacturer	Part Number
95	8	604.0 1/10W 1% 0603	R45,R54,R62,R65, R69,R77,R90,R93	DIGI-KEY	311-604HRTR-ND
96	2	90.9K 1/10W 1% 0603	R146,R151	DIGI-KEY	311-90.9KHRTR-ND
97	2	0.1 1/10W 1% 0603	R143,R149	PANASONIC	ERJ-3RSFR10V
98	3	10.0K 1/10W 1% 0603	R145,R147,R182	DIGI-KEY	311-10.0KHRTR-ND
99	4	5.76K 1/10W 1% 0603	R111-112, R117-118	DIGI-KEY	311-5.76KHRTR-ND
100	12	100PF 50V 5% 0603	C94,C99,C105, C117,C125,C131-132,C140,C155, C161,C166-167	AVX	06035A101JAT2A
101	4	1000PF 50V 5% 0603	C156-157, C164-165	PANASONIC	ECJ-1VC1H102J
102	1	33PF 50V 5% 0603	C225	AVX	06035A330JAT2A
103	1	47.5K 1/10W 1% 0603	R183	DIGI-KEY	311-47.5KHRTR-ND
104	8	220PF 50V 5% 0603	C89,C97,C103, C109,C121,C127, C136,C139	PANASONIC	ECJ-1VC1H221J
105	12	680PF 50V 5% 0603	C96,C102,C108, C115,C122,C128, C135,C141,C148-149,C158,C160	PANASONIC	ECJ-1VC1H681J
106	9	2200PF 50V 5% 0603	C88,C98,C104, C110,C120,C126, C137-138,C219	PANASONIC	ECJ-1VB1H222K
107	8	2.74K 1/10W 1% 0603	R38,R47,R53,R61, R70,R78,R89,R98	DIGI-KEY	311-2.74KHRTR-ND


ADSP-21375 EZ-KIT Lite Bill Of Materials

Ref.	Qty.	Description	Reference Designator	Manufacturer	Part Number
108	4	1UF 6.3V 20% 0402	C197-200	PANASONIC	ECJ-0EB0J105M
109	6	100 1/16W 5% 0402	R136-137, R165-167,R179	DIGI-KEY	311-100JRTR-ND
110	1	0.027UF 25V 5% 0603	C181	AVX	06033C273JAT2A
111	2	0.27UF 16V 20% 0603	C180,C182	AVX	0603YG274ZAT2A
112	2	2.05K 1/16W 1% 0402	R100-101	VISHAY	CRCW04022K05FKED
113	1	232.0 1/16W 1% 0603	R129	DIGI-KEY	311-232HRTR-ND
114	2	301.0 1/16W 1% 0603	R105-106	DIGI-KEY	311-301HRTR-ND
115	1	24.9K 1/10W 1% 0603	R17	DIGI-KEY	311-24.9KHTR-ND
116	1	47UF 6.3V 10% B	CT5	PANASONIC	EEE0JA470WR
117	1	511.0 1/16W 1% 0402	R135	DIGI-KEY	311-511LCT-ND
118	1	0.05 1/2W 1% 1206	R16	SUSUMA	RL16326-R050-F-N
119	1	10UF 16V 10% 1210	C3	AVX	1210YD106KAT2A
120	1	GREENLED001	LED9	PANASONIC	LN1361CTR
121	1	REDLED001	LED10	PANASONIC	LN1261CTR
122	1	255.0K 1/10W 1% 0603	R35	VISHAY	CRCW06032553FK

Ref.	Qty.	Description	Reference Designator	Manufacturer	Part Number
123	1	80.6K 1/10W 1% 0603	R181	DIGI-KEY	311-80.6KHRCT-ND
124	1	6.8UH 25% IND009	L3	DIGI-KEY	308-1328-1-ND



ADSP-21375 EZ-KIT Lite Schematic

		ANALOG DEVICES	20 Cotton Road Nashua, NH 03063 PH: 1-800-ANALOGD
Title		ADSP-21375 EZ-KIT Lite TITLE	
Size C	Board No.	A0202-2006	Rev 1.0A
Date	6-15-2007_13:43	Sheet	1 of 13



DATA[16:31] only used for 21371 not 21375


When designing your JTAG interface please refer to the Engineer to Engineer Note EE-68 which can be found at <http://www.analog.com>



SW2: BOOT/CLOCK RATIO SELECT
(Default: 1=ON, 2=OFF, 3=ON, 4=OFF)

1	2	BOOTMODE	
BOOTCFG0 ON	BOOTCFG1 ON	SPI SLAVE BOOT	DEFAULT
BOOTCFG0 ON	BOOTCFG1 OFF	EPROM/FLASH BOOT	
BOOTCFG0 OFF	BOOTCFG1 ON	SPI MASTER BOOT	
BOOTCFG0 OFF	BOOTCFG1 OFF	RESERVED	
3	4	CLOCK RATIO	
CLKCFG0 ON	CLKCFG1 ON	CORE:CLKIN	DEFAULT
CLKCFG0 ON	CLKCFG1 OFF	6:1	
CLKCFG0 OFF	CLKCFG1 ON	16:1	
CLKCFG0 OFF	CLKCFG1 OFF	32:1	
		RESERVED	



XTAL PIN TEST POINT
DO NOT POPULATE C1











ANALOG DEVICES

20 Cotton Road
Nashua, NH 03063
PH: 1-800-ANALOGD

Title			ADSP-21375 EZ-KIT Lite DSP		
Size C	Board No.	A0202-2006		Rev	1.0A
Date	6-15-2007_13:43		Sheet	2 of 13	



R3,R4,R7,R8,C21,C38 ONLY NEEDED FOR 21371
 Pins are Not Connected on 21375




All USB interface circuitry is considered proprietary and has been omitted from this schematic.

When designing your JTAG interface please refer to the Engineer to Engineer Note EE-68 which can be found at <http://www.analog.com>


		20 Cotton Road Nashua, NH 03063 PH: 1-800-ANALOGD	
Title ADSP-21375 EZ-KIT Lite DSP 2			
Size C	Board No. A0202-2006	Rev 1.0A	
Date 6-15-2007_13:43	Sheet 3 of 13		

21375 EZ-Kit SDRAM
128Mb (2M x 16-bit x 4 Banks)




DQM signals are either tied to GND or driven by processor's FLAG pin. This is SDRAM device specific and the requirement is specified in SDRAM datasheets

21371 EZ-Kit SDRAM
128Mb (1M x 32-bit x 4 Banks)





DQM signals are either tied to GND or driven by processor's FLAG pin. This is SDRAM device specific and the requirement is specified in SDRAM datasheets


Flash
8Mb (1M x 8-bit)




SPI Flash
2Mb



21375 SDRAM




21371 SDRAM




ANALOG DEVICES

20 Cotton Road
Nashua, NH 03063
PH: 1-800-ANALOGD


Title			ADSP-21375 EZ-KIT Lite MEMORY		
Size	Board No.				Rev
C	A0202-2006				1.0A
Date	9-7-2007_14:44	Sheet	4 of	13	



AD1835 AUDIO CODEC





- ADC
- DAC1
- DAC2
- DAC3
- DAC4




SW3: CODEC SETUP SWITCH
(Default: 1=OFF, 2=ON, 3=ON, 4=ON)

1-2	Connects or disconnects the audio oscillator depending on how the system is setup. See users manual for more information.
3	OFF = AD1835 is SLAVE ON = AD1835 is MASTER
4	Disconnects ADC_DATA signal from driving the corresponding DAI signal. Useful if using this DAI pin for another purpose.

DISCONNECTS SPI FROM FLASH AND AD1835








Loopback Test Switch
(Default= All OFF)
For Test Purposes Only




ANALOG DEVICES


20 Cotton Road
Nashua, NH 03063
PH: 1-800-ANALOGD

Title ADSP-21375 EZ-KIT Lite ANALOG AUDIO		
Size C	Board No. A0202-2006	Rev 1.0A
Date 6-15-2007_13:43	Sheet 5 of 13	




 ANALOG DEVICES		20 Cotton Road Nashua, NH 03063 PH: 1-800-ANALOGD	
		Title ADSP-21375 EZ-KIT Lite AUDIO OUT 1	
Size C	Board No.	A0202-2006	Rev
Date	6-15-2007_13:43	Sheet	6 of 13


DAC3 LEFT





DAC4 LEFT





DAC3 RIGHT



DAC4 RIGHT





 ANALOG DEVICES		20 Cotton Road Nashua, NH 03063 PH: 1-800-ANALOGD	
		Title ADSP-21375 EZ-KIT Lite AUDIO OUT 2	
Size C	Board No. A0202-2006	Rev 1.0A	
Date 6-15-2007_13:43	Sheet 7 of 13		




ADC LEFT

DAC4 HEADPHONE OUT






ADC RIGHT





ELECTRET MICROPHONE ENABLE SWITCH (Default = All OFF)


WHEN USING AN ELECTRET MICROPHONE PLACE ALL SWITCHES IN ON POSITION







 ANALOG DEVICES		20 Cotton Road Nashua, NH 03063 PH: 1-800-ANALOGD	
		Title ADSP-21375 EZ-KIT Lite AUDIO IN & HEADPHONE OUT	
Size C	Board No. A0202-2006	Rev 1.0A	
Date 6-15-2007_13:43	Sheet 8 of 13		



 ANALOG DEVICES		20 Cotton Road Nashua, NH 03063 PH: 1-800-ANALOGD	
		Title ADSP-21375 EZ-KIT Lite PUSHBUTTONS, LEDS, & RESET	
Size C	Board No. A0202-2006	Rev 1.0A	
Date 6-15-2007_13:43	Sheet 11 of 13		






EXPANSION INTERFACE (TYPE A)








 ANALOG DEVICES		20 Cotton Road Nashua, NH 03063 PH: 1-800-ANALOGD	
		Title ADSP-21375 EZ-KIT Lite EXPANSION INTERFACE	
Size C	Board No. A0202-2006	Rev 1.0A	
Date 6-15-2007_13:43	Sheet 12 of		13


POWER IN



VDDINT_SHUNT = 1.2V
 VDDINT_SHUNT = 0.8V(1 + R188/R189)



GND Test Points are scattered on PCB for Test Measurement Purposes.
 LABEL "GND" ON ALL TPs



		20 Cotton Road Nashua, NH 03063 PH: 1-800-ANALOGD	
		Title ADSP-21375 EZ-KIT Lite POWER	
Size C	Board No. A0202-2006	Rev 1.0A	
Date 6-15-2007_13:43	Sheet 13 of 13		

I INDEX

A

- AD1835A, CAD and DAC
 - configuration registers, [1-10](#)
 - DAI interface, [1-10](#)
 - disconnect switch (SW15), [2-15](#)
 - DPI interface, [2-6](#)
 - master clock (MCLK), [2-5](#), [2-11](#)
 - master/slave modes, [1-10](#), [2-11](#)
 - setup switch (SW3), [2-11](#)
- ADC_DATA pins, [2-11](#)
- ADDR23-0 pins, [2-7](#)
- AMP_LEFT_IN signals, [2-13](#)
- AMP_RIGHT_IN signals, [2-13](#), [2-14](#)
- analog audio, *See* audio, AD1835A
- analog-to-digital converters (ADCs), *See* AD1835A
- architecture, of this EZ-KIT Lite, [2-2](#)
- async memory controller, [1-9](#)
- audio
 - codecs, *See* AD1835A
 - in RCA connector (J10), [2-22](#)
 - interface, [xi](#), [1-10](#)
 - oscillators, [2-4](#), [2-11](#)
 - out RCA connector (J5), [2-22](#)

B

- background telemetry channel (BTC), [1-13](#)
- bill of materials, [A-1](#)
- board schematic (ADSP-21375), [B-1](#)

boot

- configuration pins (BOOTCFG1-0), [2-10](#)
- modes, [2-3](#), [2-10](#)

C

- CLKCFG1-0 pins, [2-3](#), [2-10](#)
- CLKIN pins, [2-3](#), [2-10](#)
- clock
 - multiplier ratios, [2-10](#)
 - routing signals, [2-11](#)
- codec
 - See also* AD1835A
 - disconnect switch (SW15), [2-15](#)
 - setup switch (SW7), [2-11](#)
- configuration, of this EZ-KIT Lite, [1-4](#)
- connectors
 - diagram of locations, [2-21](#)
 - J10 (audio in RCA), [1-11](#), [2-22](#)
 - J1-3 (expansion), [2-3](#), [2-5](#), [2-6](#), [2-7](#), [2-22](#)
 - J4 (power), [1-5](#), [2-23](#)
 - J5 (audio out RCA), [1-11](#), [2-22](#)
 - J6 (RS-232), [xi](#)
 - J7-8 (S/PDIF coax), [2-24](#)
 - J9 (headphone out), [1-11](#), [2-23](#)
 - P3 (DPI header), [2-24](#)
 - P4 (DAI header), [2-24](#)
 - ZP4 (JTAG), [2-8](#), [2-25](#)
- contents, of this EZ-KIT Lite package, [1-2](#)

INDEX

core

- clock rates, [2-10](#)
 - frequency, [2-3](#)
 - to CLKIN ratios, [2-10](#)
 - voltage, [2-2](#)
- current limits, [2-8](#)
- customer support, [xv](#)

D

- DAC1-0 signals, [2-14](#)
- DAI
- block diagram, [2-4](#)
 - connections, [1-11](#), [1-12](#), [2-16](#)
 - data transfer from codec, [1-10](#)
 - disabling (SW3), [2-5](#), [2-11](#)
 - header (P4), [2-4](#), [2-24](#)
- DAI16-15 pins, [1-12](#)
- DAI20-19 pins, [2-13](#), [2-17](#)
- DAI4 pins, [2-20](#)
- DAIP20-11 pins, [2-7](#)
- DATA31-0 pins, [2-7](#)
- data acquisition (DAQ) devices, [1-9](#)
- DB9 connectors, [xi](#)
- default configuration, of this EZ-KIT Lite, [1-3](#)
- digital peripheral interface, *See* DPI
- digital-to-analog converters (DACs), *See* AD1835A
- DIP switch (SW7), [1-4](#), [1-11](#), [2-13](#), [2-17](#)
- DPI
- block diagram, [2-5](#)
 - connections, [1-8](#), [1-12](#), [2-16](#)
 - disabling (SW2), [2-6](#)
 - header (P3), [2-6](#), [2-24](#)
- DPI12-10 pins, [2-7](#), [2-12](#)
- DPI14-13 pins, [1-12](#), [2-7](#)
- DPI2-1 (MOSI-0) pins, [1-8](#), [2-7](#)
- DPI3 (SPI clock) pins, [1-8](#), [2-7](#)
- DPI4 pins, [1-10](#), [2-7](#)
- DPI5 (chip select) pins, [1-8](#), [2-7](#)
- DPI8-6 pins, [1-12](#), [2-7](#)

E

- electret microphone, [1-11](#), [2-12](#)
- ELVIS (Educational Laboratory Virtual Instrumentation Suite)
- interface, [1-9](#)
 - programmable flag jumper (JP4), [2-20](#)
 - select jumper (JP2), [2-19](#)
 - trigger pins, [2-20](#)
 - voltage select jumper (JP3), [2-20](#)
- EPROM/flash boot mode, [2-3](#)
- example programs, [1-13](#)
- expansion interface, [2-3](#), [2-5](#), [2-6](#), [2-7](#), [2-22](#)
- external
- memory, [1-8](#)
 - phase lock loop, *See* PLL
 - ports, [2-3](#), [2-10](#)

F

- features, of this EZ-KIT Lite, [x](#)
- FLAG0 pins, [1-12](#), [2-6](#), [2-7](#), [2-13](#), [2-17](#)
- FLAG1 pins, [1-12](#), [2-6](#), [2-7](#), [2-13](#), [2-17](#)
- FLAG2 pins, [2-6](#), [2-7](#)
- FLAG3 pins, [1-12](#), [2-6](#), [2-7](#), [2-16](#)
- FLAG registers, [1-11](#)
- flash memory
- boot mode (default), [2-10](#)
 - disconnect switch (SW15), [2-15](#)
 - start/end addresses, [1-8](#)
 - via external port, [1-7](#), [2-3](#)
- frame sync/clock signals, [1-10](#), [2-11](#)
- FUNCT_OUT signals, [2-14](#)

G

- general-purpose IO pins, [1-11](#), [2-6](#), [2-16](#), [2-17](#)

H

- headphone out jack (J9), [2-23](#)

I

installation, of this EZ-KIT Lite, 1-5
 interrupts, config push buttons as, 1-11
 IO voltage, 2-2
 -IRQ0 pins, 1-12, 2-13, 2-17
 -IRQ1 pins, 1-12, 2-13, 2-17
 -IRQ3 pins, 1-12

J

JTAG

emulation port, 2-8
 header (ZP4), 2-25

jumpers

diagram of locations, 2-18
 JP1 (VCO select), 2-19
 JP2 (ELVIS select), 2-19
 JP3 (voltage select), 2-20
 JP4 (ELVIS programmable flag), 2-20
 JP6 (ELVIS voltage), 2-20

L

LabVIEW virtual instruments, xi, 1-9

LEDs

diagram of locations, 2-15
 LED10 (reset), 1-5, 2-16
 LED1-7 (FLAGx IO), 1-12, 2-16
 LED8 (FLAG3), 1-12, 2-6, 2-16
 LED9 (power), 1-5, 2-16
 ZLED3 (USB monitor), 1-5, 2-16

LEFT_IN signals, 2-14

LEFT_OUT signals, 2-13, 2-14

license restrictions, 1-7

loop-back test switches (SW6, SW14), 2-12

M

-M2-0 memory select pins, 1-8
 master input clock (MCLK), 1-10
 -MS3 memory select pins, 1-8, 1-12

N

notation conventions, xxi

O

oscilloscope config switch (SW1), 2-13

P

package contents, 1-2
 parallel flash memory, *See* flash memory
 parallel port control signals, 2-7
 phase lock loop (PLL), xii, 2-4, 2-19
 PMCTL registers, 2-3
 power
 connector (J4), 2-23
 LED (LED9), 2-16
 specifications, 2-23
 supply, 2-20, 2-23
 push buttons
 diagram of locations, 2-15
 See also switches by name (SWx)
 enable switch (SW7), 1-4, 1-11, 2-13, 2-17

R

RCA

cables, 1-3
 connectors, xi, 1-11, 2-4

reset

LED (LED10), 2-16
 push button (SW12), 2-17

restrictions, of the evaluation license, 1-7

RIGHT_IN signals, 2-14

RIGHT_OUT signals, 2-13, 2-14

RS-232 connector (J6), xi

S

schematic, of ADSP-21375 EZ-KIT Lite, B-1

INDEX

SDRAM

- chip select pin (FLAG8), [2-6](#)
 - controller, [1-8](#)
 - control signals, [2-7](#)
 - via external port, [2-3](#)
- serial peripheral interface, *See* SPI
- setup, of this EZ-KIT Lite, [1-3](#)
- signal routing units
- SRU2 (DPI interface), [2-5](#)
 - SRU (DAI interface), [2-4](#)
- spacing headers, [2-24](#)
- ## SPI
- flash memory, [1-7](#), [1-8](#), [2-6](#)
 - master/slave boot modes, [2-3](#), [2-10](#)
 - port, [1-8](#), [1-10](#)
- startup, of this EZ-KIT Lite, [1-5](#)
- SW12 (reset) push button, [2-17](#)
- SW13 (ELVIS station) switch, [2-14](#)
- SW14 (test) switch, [2-12](#)
- SW15 (AD1835A and flash disconnect) switch, [2-15](#)
- SW1 (oscilloscope) switch, [2-13](#)
- SW2 (boot mode select) switch, [2-3](#), [2-6](#), [2-10](#)
- SW3 (AD1835A codec) switch, [2-5](#), [2-11](#)
- SW4 (microphone) switch, [1-11](#), [2-12](#)
- SW6 (test) switch, [2-12](#)
- SW7 (push button enable) DIP switch, [1-4](#), [1-11](#), [2-13](#), [2-17](#)
- SW8-11 (general input) push buttons, [2-17](#)

- synchronous dynamic random access memory, *See* SDRAM
- system architecture, of this EZ-KIT Lite, [2-2](#)

T

- test switches (SW6, SW14), [2-12](#)
- time-division multiplexed (TDM) mode, [1-10](#)
- two-wire interface (TWI) mode, [1-10](#)

U

UART

- enable switch (SW5)
 - interface, [xi](#), [2-6](#)
- universal asynchronous receiver/transmitter, *See* UART

USB

- cable, [1-3](#), [1-5](#), [2-16](#), [2-17](#)
- interface, [2-8](#), [2-25](#)
- interface chip (U34), [2-17](#)
- monitor LED (ZLED3), [1-5](#), [2-16](#)

V

VisualDSP++

- environment, [1-5](#)
- voltage-controlled oscillator select jumper (JP1), [2-19](#)