

Instructions for Assembly:

- 1. Place flange on the baffle plate over the spline in the grill of the Sonalert.
- 2. Attach shutter to the baffle plate.
- Insert Snap Rivet or Screw through the center hole of the shutter and baffle plate. Snap Rivet: Push the Snap Rivet into the front center hole until it snaps tightly into place. Screw: Secure the screw into the front center hole of the Sonalert. Do not over tighten.
- 4. Adjust volume by rotating the shutter