


PIN RECEPTACLES With Organic Fibre Plug[®] Solder Barrier

6

0

3



- After soldering, the *OFP*^(R) barrier is pushed out of the receptacle when the device is plugged in.
- All parts are available as discrete receptacles; but for SMT assembly, certain receptacles are supplied on carrier tape per EIA-481 to feed industry standard pick and place machines.

*Intrusive reflow (also called "pin-in-paste") is a technique of using conventional thru-hole components in a reflow soldering process. The receptacles

