


# Product Configuration System



## MHz Range Crystal Units



### NOTES:

- 1) If you require a load capacitance other than the above listed, please contact your EEA representative for assistance.
- \*2) For frequencies between 26.0000MHz and 29.9999MHz, please specify "(FUND)" at end of part number if fundamental mode required. Otherwise, 3rd Overtone is default.