

➔ **LinuxLink by TimeSys**
for Atmel AT91SAM9 Microcontrollers

A complete web-based resource for embedded Linux development

AT91SAM9 Microcontrollers

The Atmel® AT91SAM9 series based on the 200+ MIPS ARM926EJ-S™ processor, offers a flexible configuration of on- and off-chip memories together with an extensive set of peripherals for control, communication and data storage purposes. These include USB Host and Device and Ethernet 10/100 Base-T MAC as well as interfaces for a variety of Flash cards including Atmel's DataFlash®.

All AT91SAM9 microcontrollers are Linux®-enabled for applications requiring a full-feature open source operation system.



What is LinuxLink?

LinuxLink by TimeSys™ is a complete, Web-based resource for embedded Linux development targeting. Every LinuxLink subscription includes:

- Hundreds of cross-compiled, ready-to-use application examples
- The latest Atmel-developed Linux optimized for your Atmel AT91 ARM9™-based microcontroller
- Developer Exchange community access
- A cross-development environment
- Access additional information on <http://linuxlink.timesys.com/atmel>


**One-month
GETTING STARTED
subscription!**

**ONE MONTH
FREE
INCLUDES DEVELOPER EDITION**

**Use your
ACTIVATION CODE
on the back**



LinuxLink by TimeSys for Atmel AT91SAM9 Microcontrollers



Get started with commercial Linux right out of the box

Get the latest Linux from Atmel, optimized and tested on reference boards for the AT91SAM9 processors, while receiving updates and patches throughout your development cycle.

Create your own commercial-grade custom Linux platform faster and with less effort

Cut weeks or months from your development process by tapping into hundreds of cross-compiled, ready-to-use Linux applications available through the LinuxLink component repository, already validated on AT91SAM9 processors.

Focus on application development while simplifying feature, performance and footprint optimization for your Linux platform

Use a robust processor-optimized cross-development environment with compilers, application and kernel debuggers, and platform development tools. Access releases and patches created by Atmel engineering as soon as they become available.

Tap into community expertise, technical information and best practices

Support your embedded Linux project by using the Developer Exchange for online, interactive support from TimeSys, Atmel, and the Open Source community. Whenever you have a problem or question, you can get in touch with the right people right away.



Take advantage of a free subscription to LinuxLink for any Atmel ARM9-based Microcontroller

For ONE MONTH FREE access to LinuxLink, enter the activation code below on:

<http://linuxlink.timesys.com/atmel>

Product	Activation Code
AT91RM9200	c622ae04
AT91SAM9260	cc73f78f
AT91SAM9261	cabd70a0

Disclaimer: The information in this document is provided in connection with Atmel products. No license, express or implied, by estoppel or otherwise, to any intellectual property right is granted by this document or in connection with the sale of Atmel products. EXCEPT AS SET FORTH IN ATMEL'S TERMS AND CONDITIONS OF SALES LOCATED ON ATMEL'S WEB SITE, ATMEL ASSUMES NO LIABILITY WHATSOEVER AND DISCLAIMS ANY EXPRESS, IMPLIED OR STATUTORY WARRANTY RELATING TO ITS PRODUCTS INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT. IN NO EVENT SHALL ATMEL BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, PUNITIVE, SPECIAL OR INCIDENTAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS AND PROFITS, BUSINESS INTERRUPTION, OR LOSS OF INFORMATION) ARISING OUT OF THE USE OR INABILITY TO USE THIS DOCUMENT, EVEN IF ATMEL HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Atmel makes no representations or warranties with respect to the accuracy or completeness of the contents of this document and reserves the right to make changes to specifications and products descriptions at any time without notice. Atmel does not make any commitment to update the information contained herein. Unless specifically provided otherwise, Atmel products are not suitable for, and shall not be used in, automotive applications. Atmel's products are not intended, authorized, or warranted for use as components in applications intended to support or sustain life.

Atmel Corporation
2325 Orchard Parkway
San Jose, CA 95131, USA
Tel.: (1)408 441-0311
Fax: (1)408 487-2600

Regional Headquarters Europe

Atmel Sarl
Route des Arsenaux 41
Case Postale 80
CH-1705 Fribourg
Switzerland
Tel.: (41) 26-426-5555
Fax: (41) 26-426-5500

Asia

Room 1219
Chinachem Golden Plaza
77 Mody Road Tsimshatsui
East Kowloon
Hong Kong
Tel.: (852) 2721-9778
Fax: (852) 2722-1369

Japan

9F, Tonetsu Shinkawa Bldg.
1-24-8 Shinkawa
Chuo-ku, Tokyo 104-0033
Japan
Tel.: (81) 3-3523-3551
Fax: (81) 3-3523-7581

Product Contact

Zone Industrielle
13106 Rousset Cedex
France
Tel.: (33) 442-53-6000
Fax: (33) 442-53-6001

Literature Requests

www.atmel.com/literature

Web Site

www.atmel.com

© 2006 Atmel Corporation.
All rights reserved.

Atmel®, logo and combinations thereof, Everywhere You Are®, DataFlash® and others are registered trademarks, SAM-BA™ and others are trademarks, of Atmel Corporation or its subsidiaries. ARM® and others are the registered trademarks, AMBA™, ARM9™ and others are trademarks of ARM Ltd. Other terms and product names may be trademarks of others.

Rev.: 6246A-ATARM-07/06/2M

