


Hand Crimp Tool Operating Instruction And Specifications Sheet Order No. 64001-1500 Eng. No. RHT 2200 (Replaces 19285-0018)



FEATURES

- A full cycle ratcheting hand tool ensures complete crimps
- Long handles for comfortable crimping with reduced crimping force
- A precision user-friendly terminal locator wire stop holds terminals in the proper crimping position
- Insulation crimp adjustment allows a precise insulation crimp. To meet or exceed the requirements of UL, CSA and Military Class II
- Single color-coded crimp pocket eliminates the possibility of using the wrong pocket

SCOPE

AviKrimp® and InsulKrimp®Terminals and Splices 10-12 AWG, (Rings, Spades, Hooks, Snap Spades and Flanged Spades, Wire Pin Terminals and also 3 to 4 way connectors). Also terminates ends of step down butt splice 10-12 to 14-16 AWG.

Testing

Mechanical

The tensile test, or pull test, is a means of evaluating the mechanical properties of the crimped connections. The following charts show the UL specifications for various wire sizes. The tensile strength is shown in

Wire Size (AWG)	*UL - 486 A	*UL – 486 C
16	N/A	15
14	N/A	25
12	70	35
10	80	40

pounds and indicates the minimum acceptable force to break or separate the terminal from the conductor.

*UL - 486 A - Terminals (Copper conductors only) *UL - 486 C - Butt Splices

The following is a partial list of the product part numbers and their specifications that this tool is designed to run. We will be adding to this list and an up to date copy is available on <u>www.molex.com</u>.

debigned to			#mg to t	ino not	und un	
Wire Size: 10 – 12 AWG 5.00 – 3.00 mm ²						
Terminal No.	Terminal	Wire Stri	p Length	Insul. D	ia. Max.	
Terminai No.	Eng No. (REF)	In	mm	In	mm	
19070-0119	C-228-06X	.375	9.53	250	6.35	
19070-0121	C-228-08X	.375	9.53	.250	6.35	
19070-0123	C-228-10X	.375	9.53	.250	6.35	
19070-0130	C-230-10X	.375	9.53	.250	6.35	
19070-0132	C-230-14X	.375	9.53	.250	6.35	
19070-0136	C-230-56X	.375	9.53	.250	6.35	
19070-0143	C-236-06X	.375	9.53	.250	6.35	
19070-0145	C-236-08X	.375	9.53	.250	6.35	
19070-0150	C-240-14X	.375	9.53	.250	6.35	
19070-0153	C-240-38X	.375	9.53	.250	6.35	
19070-0155	C-240-56X	.375	9.53	.250	6.35	
19073-0145	C-801-12	.375	9.53	.225	5.72	
19073-0147	C-801-12X	.375	9.53	.250	6.35	
19073-0160	C-828-06	.375	9.53	.225	5.72	
19073-0163	C-828-06X	.375	9.53	.250	6.35	

date copy is available on <u>www.molex.com</u> .							
Wire Size: 10 – 12 AWG 5.00 – 3.00 mm ²							
Terminal	Wire Stri	ip Length	Insul. D	ia. Max.			
Eng No. (REF)	In	mm	In	mm			
C-828-08	.375	9.53	.225	5.72			
C-828-08X	.375	9.53	.250	6.35			
C-828-10	.375	9.53	.225	5.72			
C-828-10X	.375	9.53	.250	6.35			
C-830-10	.375	9.53	.225	5.72			
C-830-10X	.375	9.53	.250	6.35			
C-830-10XLBK	.375	9.53	.225	5.92			
C-830-10XX	.375	9.53	.320	8.13			
C-830-14	.375	9.53	.225	5.72			
C-830-14X	.375	9.53	.250	6.35			
C-830-14XLBK	.375	9.53	.225	5.92			
C-830-14XX	.375	9.53	.320	8.13			
C-830-56	.375	9.53	.225	5.72			
C-830-56X	.375	9.53	.250	6.35			
C-830-56XLBK	.375	9.53	.225	5.92			
	Wire Size: 10 – 12 Terminal Eng No. (REF) C-828-08 C-828-08X C-828-10X C-828-10X C-830-10X C-830-10X C-830-10XLBK C-830-10XX C-830-14X C-830-14XLBK C-830-14XLBK C-830-14XX C-830-56 C-830-56X	Wire Size: 10 – 12 AWG 5.00 Terminal Wire Stri Eng No. (REF) In C-828-08 .375 C-828-08X .375 C-828-10 .375 C-828-10X .375 C-828-10X .375 C-830-10X .375 C-830-10X .375 C-830-10XLBK .375 C-830-10XX .375 C-830-10XX .375 C-830-10XX .375 C-830-10XX .375 C-830-14X .375 C-830-14X .375 C-830-14XX .375 C-830-14XX .375 C-830-56 .375	Wire Size: 10 – 12 AWG 5.00 – 3.00 mm Terminal Wire Strip Length Eng No. (REF) In mm C-828-08 .375 9.53 C-828-08X .375 9.53 C-828-08X .375 9.53 C-828-10X .375 9.53 C-828-10X .375 9.53 C-828-10X .375 9.53 C-830-10X .375 9.53 C-830-10X .375 9.53 C-830-10XX .375 9.53 C-830-10XX .375 9.53 C-830-10XLBK .375 9.53 C-830-10XLBK .375 9.53 C-830-10XX .375 9.53 C-830-14X .375 9.53 C-830-14X .375 9.53 C-830-14XX .375 9.53 C-830-14XX .375 9.53 C-830-14XX .375 9.53 C-830-566 .375 9.53	Wire Size: 10 – 12 AWG 5.00 – 3.00 mm ² Terminal Wire Strip Length Insul. D Eng No. (REF) In mm In C-828-08 .375 9.53 .225 C-828-08X .375 9.53 .225 C-828-10 .375 9.53 .225 C-828-10X .375 9.53 .225 C-828-10X .375 9.53 .225 C-828-10X .375 9.53 .225 C-830-10X .375 9.53 .225 C-830-10X .375 9.53 .225 C-830-10XLBK .375 9.53 .225 C-830-10XX .375 9.53 .225 C-830-14X .375 9.53 .225 C-830-14X .375 9.53 .225 C-830-14XLBK .375 9.53 .225 C-830-14XX .375 9.53 .320 C-830-14XX .375 9.53 .320 C-830-56 .375<			

 Doc No.
 64001-1500 Release Date:
 01-15-03

 Revision: C
 Revision Date:
 01-10-06

UNCONTROLLED COPY

Page 1 of 7

RHT 2200 Hand Crimp Tool

	Wire Size: 10 – 12	2 AWG 5.00	0 – 3.00 mm	n ²	
	Terminal		ip Length		ia. Max.
Terminal No.	Eng No. (REF)	In	mm	In	mm
19073-0206	C-830-56XX	.375	9.53	.320	8.13
19073-0216	C-836-06	.375	9.53	.225	5.72
19073-0220	C-836-06X	.375	9.53	.250	6.35
19073-0222	C-836-08	.375	9.53	.225	5.72
19073-0225	C-836-08X	.375	9.53	.250	6.35
19073-0227	C-840-10	.375	9.53	.225	5.72
19073-0229	C-840-10X	.375	9.53	.250	6.35
19073-0231	C-840-14	.375	9.53	.225	5.72
19073-0233	C-840-14X	.375	9.53	.250	6.35
19073-0236	C-840-38	.375	9.53	.225	5.72
19073-0238	C-840-38X	.375	9.53	.250	6.35
19073-0242	C-840-56	.375	9.53	.225	5.72
19073-0244	C-840-56X	.375	9.53	.250	6.35
19073-0272	C-830-10XXBK	.375	9.53	.320	8.13
19073-0273	C-830-14XXBK	.375	9.53	.320	8.13
19073-0274	C-830-56XXBK	.375	9.53	.320	8.13
19081-0005	C-5006-MS	.375	9.53	.225	5.72
19090-0083	C-212-08X	.375	9.53	.250	6.35
19090-0085	C-212-10X	.375	9.53	.250	6.35
19099-0044	C-2710-06X	.375	9.53	.225	5.72
19099-0048	C-2718-08X	.375	9.53	.225	5.72
19099-0050	C-2719-10X	.375	9.53	.225	5.72
19115-0033	C-8196-06	.375	9.53	.225	5.72
19115-0035	C-8197-08	.375	9.53	.225	5.72
19115-0037	C-8198-10	.375	9.53	.225	5.72
19115-0039	C-8199-14	.375	9.53	.225	5.72
19115-0041	C-8710-05	.375	9.53	.225	5.72
19115-0042	C-8710-06	.375	9.53	.225	5.72
19115-0046	C-8718-08	.375	9.53	.225	5.72
19115-0048	C-8719-10	.375	9.53	.225	5.72
19127-0086	C-817-08	.375	9.53	.225	5.72

	Wire Size: 10 – 12	2 AWG 5.0	0 – 3.00 mr	n ²	
Terminal No.	Terminal		ip Length		ia. Max.
	Eng No. (REF)	In	mm	In	mm
19127-0089	C-817-10	.375	9.53	.225	5.72
19139-0060	C-8105-08	.375	9.53	.225	5.72
19144-0037	C-241-06X	.375	9.53	.250	6.35
19144-0039	C-241-08X	.375	9.53	.250	6.35
19144-0042	C-241-10X	.375	9.53	.250	6.35
19144-0046	C-268-14X	.375	9.53	.250	6.35
19154-0028	C-246X	.225	5.95	.225	5.72
19154-0037	CS-V-346X	.281	7.14	.225	5.72
19183-0019	C-811-10	.375	9.53	.225	5.72
19198-0039	C-8105-06	.375	9.53	.225	5.72
19198-0044	C-841-06	.375	9.53	.225	5.72
19198-0047	C-841-08	.375	9.53	.225	5.72
19198-0050	C-841-10	.375	9.53	.225	5.72
19198-0056	C-868-14	.375	9.53	.225	5.72
19198-0057	C-868-14X	.281	7.14	.250	6.35
19204-0025	C-2XCX	.375	9.53	.225	5.72
19204-0026	C-2YCX	.375	9.53	.225	5.72
19204-0029	C-5XC	.375	9.53	.225	5.72
19204-0030	C-5YC	.375	9.53	.225	5.72
19206-0010	CS-V-303X	.281	7.14	.260	6.60
19212-0001	WP-2210X	.281	7.14	.250	6.35
19213-0007	WP-8210	.281	7.14	.225	5.72


	STEP DOW Wire Size: 10 – 12 to 14 -16 AV	2 AWG 5.0	0 – 3.00 mn	1 ²	
Terminal No.	Terminal	Wire Stri	p Length	Insul. D	ia. Max.
	Eng No. (REF)	In	mm	In	mm
19154-0035	CB-646X	.281	7.14	.260	6.60

OPERATION

Open the tool by first closing the jaws sufficiently for the ratchet mechanism to release.

Crimping Terminals

- 1. Push up on the locator blade and position the terminal with the barrel facing up into the color-coded nest with front edge of the barrel against the locator (See Figure 1). Release the locator blade to hold the terminal in position.
- 2. Partially close the tool to hold the terminal in place (See Figure 2).
- 3. Insert the properly stripped wire into the terminal barrel (See Figure 2 and 3). The wires end should butt against the wire stop position of the locator. Cycle the tool.




Note: The tamper proof ratchet action will not release the tool until it has been fully closed.

R

- 4. Lift the locator blade or wire stop and remove the crimped terminal. Inspect for proper crimp location, and check for insulation closure. Locator is adjustable up and down to keep terminals straight after crimping.
- 5. If the insulation part of the crimp needs to be adjusted, first loosen the M4 screw on the bottom tool jaw, then insert a 3/32 hex wrench (supplied) into the bottom of the lower die (See Figure 5). A clockwise (CW) rotation decreases insulation crimp while a counter-clockwise (CCW) rotation increases insulation crimp. After adjusting retighten the M4 screw.
- 6. When crimping butt splices, or 3-way and 4-way terminals the locator must be removed. Splices must be aligned with the tooling visually in the insulation crimp (See Figure 4). The splice should be approximately centered inside the tooling nests (See Figure 4). Cycle the tool.

INSULATION

inst a 3/32 See ion crimp ulation als the the Splice Figure 2 s (See CONDUCTOR PUNCH INSULATION PUNCH




Note: Whenever crimping without the locator, make sure the seam of the terminal is oriented up or down in the tool if using unbrazed product, as this will provide higher pull force values.

Maintenance

It is recommended that each operator of the tool be made aware of, and responsible for, the following maintenance steps:

- 1. Remove dust, moisture, and other contaminants with a clean brush, or soft, lint free cloth.
- 2. Do not use any abrasive materials that could damage the tool.




- 3. Make certain all pins; pivot points and bearing surfaces are protected with a thin coat of high quality machine oil. Do not oil excessively. The 64001-1500 (RHT-2200) was engineered for durability, but like any fine piece of equipment it needs cleaning and lubrication for a maximum service life of trouble-free crimping. A light oil, such as 30 weight automotive oil used at the oil points shown in Figure 4, every 5,000 crimps or 3 months will significantly enhance the tool life and ensure a stable calibration.
- 4. When tool is not in use, keep the handles closed to prevent objects from becoming lodged in the crimping dies, and store the tool in a clean, dry area.

Miscrimps or Jams

1. Should this tool ever become stuck or jammed in a partially closed position, **Do Not** force the handles open or closed. The tool will open easily by lifting the ratchet release lever (See Fig.6).

How To Adjust Tool Preload (See Figure 6)

Over the life of the tool, it may be necessary to adjust tool handle preload force. Listed below are the steps required to adjust the crimping force of the hand tool to obtain proper crimp conditions:



- 1. Remove the screw and plastic cover washer. Note the setting wheel position.
- 2. Lift the setting wheel off the axle. Turn the eccentric axle with a screwdriver.
- 3. Turning the eccentric axle counter-clockwise (CCW) will increase handle force.
- 4. Replace the setting wheel to the axle, aligning the nearest notch in the setting wheel to the dowel pin.
- 5. Replace the plastic cover washer and screw.
- 6. Check the crimp specifications after tool handle preload force is adjusted.

Tool Calibration

A Certificate of Calibration (see last page) was supplied with the tool. To recalibrate this tool, pin gauge measurements should be taken in each conductor nest and compared to this chart. The tool should be lubricated prior to recalibration to ensure consistent measurements. Handle preload is factory set to 25-45 LBS. See How to Adjust Tool Preload (see Figure 6) to recalibrate.

AWG mm ² Mean Go No Go ^ ^	Nest Color Code	Wire	e Range	"X" Dime	nsion Cond	uctor Crimp	Crimp Inspection Marking
10-12 500-300 160 156 168 0	Nest Color Code	AWG	mm ²	Mean	Go	No Go	Crimp inspection warking
Vollow 10 12 5.00 5.00 .100 .100 .100	Vallow	10 - 12	5.00 - 3.00	.160	.156	.168	0
14-16* 1.30-2.00 .160 .156 .168 o	Yellow	14 - 16*	1.30 - 2.00	.160	.156	.168	0

^{* 14 - 16} End of step down butt splice only.

Warranty

This tool is for electrical terminal crimping purposes only. This tool is made of the best quality materials. All vital components are long life tested. All tools are warranted to be free of manufacturing defects for a period of 30 days. Should such a defect occur, we will repair or exchange the tool free of charge? This repair or exchange will not be applicable to altered, misused or damaged tools. This tool is designed for hand use only. Any clamping, fixturing, or use of handle extensions voids this warranty.

PIN GAUGE IN

CONDUCTOR

"CONFINING"


Х

Hand held crimping tools are intended for low volume, prototyping, or repair requirements only.
CAUTION: Repetitive use of this tool should be avoided.

PARTS LIST

Item	Order No.	Description	Quantity
	64001-1500	Hand Crimp Tool	(Fig.7)
1	64000-0076	Repair Kit (Springs, Pins and E-Rings)	1
2	63810-0000	Handle	1
3	64001-1575	Locator Assembly	1
4	64001-1570	Tooling Kit	1
		Tooling Kit Only	
5	64001-1502	Conductor Punch	1
6	64001-1501	Conductor Anvil	1
7	64001-1504	Insulation Punch	1
8	64001-1503	Insulation Anvil	1
9	N/A	4mm Dia. by 5.0mm LongRoll Pins	2**
10	N/A	#10-32 by 5/16" Long Cup Pt. Set Screw	1**

** The following purchased parts are available from an Industrial supply company such as MSC (1-800-645-7270).



Doc No. 64001-1500 Release Date: 01-15-03 Revision: C Revision Date: 01-10-06

	Certificat	e of Calibration	
Tool Order Number			at the second se
Tool Eng. Number			
Tool Revision			
Serial Number			
Date of Manufacture		_	
I	Iandle Load Ra	ange at 1 inch from the	e Tips =
			Actual =
Pin Gauge of Conductor N	est/Nests or Sh	ug height if the nest is	the "F" Crimp style.
Range Conductor Nest # 1	=	Actual =	
Range Conductor Nest # 2	=	Actual =	
Range Conductor Nest # 3	=	Actual =	
Technician	_		
Date of Calibration			
Calibration should be done Tools should be lubricated	• •		
Γ	1150 E Napervi Tel: (63	tion Tooling Group . Diehl Road lle, IL 60563 30) 969-4550 30) 505-0049	
Vie	t our Web site	e at http://www.molex.	com