

TLV2543EVM

User's Guide

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Mailing Address:

Texas Instruments
Post Office Box 655303
Dallas, Texas 75265

EVM IMPORTANT NOTICE

Texas Instruments (TI) provides the enclosed product(s) under the following conditions:

This evaluation kit being sold by TI is intended for use for **ENGINEERING DEVELOPMENT OR EVALUATION PURPOSES ONLY** and is not considered by TI to be fit for commercial use. As such, the goods being provided may not be complete in terms of required design-, marketing-, and/or manufacturing-related protective considerations, including product safety measures typically found in the end product incorporating the goods. As a prototype, this product does not fall within the scope of the European Union directive on electromagnetic compatibility and therefore may not meet the technical requirements of the directive.

Should this evaluation kit not meet the specifications indicated in the EVM User's Guide, the kit may be returned within 30 days from the date of delivery for a full refund. **THE FOREGOING WARRANTY IS THE EXCLUSIVE WARRANTY MADE BY SELLER TO BUYER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.**

The user assumes all responsibility and liability for proper and safe handling of the goods. Further, the user indemnifies TI from all claims arising from the handling or use of the goods. Please be aware that the products received may not be regulatory compliant or agency certified (FCC, UL, CE, etc.). Due to the open construction of the product, it is the user's responsibility to take any and all appropriate precautions with regard to electrostatic discharge.

EXCEPT TO THE EXTENT OF THE INDEMNITY SET FORTH ABOVE, NEITHER PARTY SHALL BE LIABLE TO THE OTHER FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

TI currently deals with a variety of customers for products, and therefore our arrangement with the user **is not exclusive**.

TI assumes **no liability for applications assistance, customer product design, software performance, or infringement of patents or services described herein**.

Please read the EVM User's Guide and, specifically, the EVM Warnings and Restrictions notice in the EVM User's Guide prior to handling the product. This notice contains important safety information about temperatures and voltages. For further safety concerns, please contact the TI application engineer.

Persons handling the product must have electronics training and observe good laboratory practice standards.

No license is granted under any patent right or other intellectual property right of TI covering or relating to any machine, process, or combination in which such TI products or services might be or are used.

Mailing Address:

Texas Instruments
Post Office Box 655303
Dallas, Texas 75265

EVM WARNINGS AND RESTRICTIONS

It is important to operate this EVM within the input voltage range of 3.3 V to 5.0 V and the output voltage range of 0 V and 5.0 V.

Exceeding the specified input range may cause unexpected operation and/or irreversible damage to the EVM. If there are questions concerning the input range, please contact a TI field representative prior to connecting the input power.

Applying loads outside of the specified output range may result in unintended operation and/or possible permanent damage to the EVM. Please consult the EVM User's Guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative.

During normal operation, some circuit components may have case temperatures greater than 30°C. The EVM is designed to operate properly with certain components above 60°C as long as the input and output ranges are maintained. These components include but are not limited to linear regulators, switching transistors, pass transistors, and current sense resistors. These types of devices can be identified using the EVM schematic located in the EVM User's Guide. When placing measurement probes near these devices during operation, please be aware that these devices may be very warm to the touch.

Mailing Address:

Texas Instruments
Post Office Box 655303
Dallas, Texas 75265

Read This First

About This Manual

The purpose of this users guide is to serve as a reference manual for the TLV2543 12-bit analog-to-digital converter evaluation module (EVM). This document provides information to assist hardware and software engineers in application development.

How to Use This Manual

This document contains the following chapters and appendixes:

Chapter 1 – Overview

Chapter 2 – Hardware Description and Operation

Chapter 3 – Software Program and Flowcharts

Notational Conventions

- Program listings, program examples, and interactive displays are shown in a special typeface similar to a typewriter. Examples use a **bold version** of the special typeface for emphasis; interactive displays use a **bold version** of the special typeface to distinguish commands that you enter from items that the system displays (such as prompts, command output, error messages, etc.).

Here is a sample program listing:

```
0011 0005 0001      .field  1, 2
0012 0005 0003      .field  3, 4
0013 0005 0006      .field  6, 3
0014 0006           .even
```

Here is an example of a system prompt and a command that you might enter:

```
C:  csr -a /user/ti/simuboard/utilities
```

- In syntax descriptions, the instruction, command, or directive is in a **bold typeface** font and parameters are in an *italic typeface*. Portions of a syntax that are in **bold** should be entered as shown; portions of a syntax that are

in *italics* describe the type of information that should be entered. Here is an example of a directive syntax:

.asect *"section name", address*

.asect is the directive. This directive has two parameters, indicated by *section name* and *address*. When you use .asect, the first parameter must be an actual section name, enclosed in double quotes; the second parameter must be an address.

- Square brackets ([and]) identify an optional parameter. If you use an optional parameter, you specify the information within the brackets; you don't enter the brackets themselves. Here's an example of an instruction that has an optional parameter:

LALK *16-bit constant [, shift]*

The LALK instruction has two parameters. The first parameter, *16-bit constant*, is required. The second parameter, *shift*, is optional. As this syntax shows, if you use the optional second parameter, you must precede it with a comma.

Square brackets are also used as part of the pathname specification for VMS pathnames; in this case, the brackets are actually part of the pathname (they are not optional).

- Braces ({ and }) indicate a list. The symbol | (read as *or*) separates items within the list. Here's an example of a list:

{ * | *+ | *- }

This provides three choices: *, *+, or *-.

Unless the list is enclosed in square brackets, you must choose one item from the list.

- Some directives can have a varying number of parameters. For example, the .byte directive can have up to 100 parameters. The syntax for this directive is:

.byte *value₁ [, ... , value_n]*

This syntax shows that .byte must have at least one value parameter, but you have the option of supplying additional value parameters, separated by commas.

Information About Cautions and Warnings

This book may contain cautions and warnings.

This is an example of a caution statement.

A caution statement describes a situation that could potentially damage your software or equipment.

This is an example of a warning statement.

A warning statement describes a situation that could potentially cause harm to you.

The information in a caution or a warning is provided for your protection. Please read each caution and warning carefully.

Related Documentation From Texas Instruments

TLV2543C, TLV2543I 12-Bit Analog-to-digital Converters With Serial Control and 11 Analog Inputs data sheet (literature number SLAS096)



Contents

1	Overview	1-1
1.1	Introduction	1-2
2	Hardware Description and Operation	2-1
2.1	Setup and Operation	2-2
2.2	Input Select Switch	2-3
2.3	Microcontroller	2-4
2.4	Power Supply Supervisor	2-4
2.5	Optical Sensor	2-5
2.6	Temperature Sensor	2-6
2.7	Voltage Variable Input (Potentiometer)	2-6
2.8	Buffered User Inputs	2-7
2.9	Unbuffered Inputs	2-7
2.10	Reference Select	2-8
2.11	Fast Conversion Rate	2-8
2.12	Input Voltage Clamp	2-8
2.13	Interface Connector Provisions	2-9
2.14	Grounding Considerations	2-9
2.15	Driving the Input of a Switched Capacitor ADC	2-11
2.16	Board Schematic	2-13
2.17	Part Descriptions	2-15
3	Software Program and Flowcharts	3-1
3.1	Software Program	3-2
3.2	Flowcharts	3-8

Figures

2-1.	Interface Connector Hole Pattern	2-9
2-2.	Equivalent Input Circuit	2-11
2-3.	Board Schematic	2-13
3-1.	Main Program Flowchart	3-8
3-2.	Initialization Subroutine Flowchart	3-9
3-3.	Read Input Switch Subroutine Flowchart	3-10
3-4.	Analog-to-Digital Convert Subroutine Flowchart	3-12
3-5.	Delay Subroutine Flowchart	3-13
3-6.	Display Subroutine Flowchart	3-14

Tables

2-1.	EVM Default Settings	2-2
2-2.	Input Select Switch Descriptions	2-3
2-3.	Buffered User Input Descriptions	2-7
2-4.	Interface Connector Hole Pattern Descriptions	2-9
2-5.	Part Descriptions	2-15

Overview

The TLV2543EVM evaluation module provides a platform for evaluating the TLV2543 analog-to-digital converter (ADC). For ease of evaluation, the ADC is interfaced with a microcontroller, three sensors, and a display. The onboard sensors provided are:

- An optical sensor
- A temperature sensor
- A variable resistor

Eight additional analog inputs are available for user-provided signals. Provisions are made for attaching these signal lines to a user-supplied connector. Terminals for an external power supply are also provided. This chapter includes the following topic:

Topic	Page
1.1 Introduction	1-2

1.1 Introduction

The TLV2543EVM consists of a TLV2543 12-bit ADC interfaced with a TSL250 optical sensor, a transistor based temperature sensor, a TL1431 voltage reference, a TLV2264 quad op-amp to provide 4 analog signal buffers, a TL7726 hex clamping circuit for signal over-voltage protection, a TMS370C712 microcontroller, three TIL311 hex display characters, and a TPS7233 3.3 volt regulator powering the TLV2543, TLC2264, 74LVC244A and the sensors.

The microcontroller reads the user-programmed dip switches and communicates with the TLV2543 to select the desired analog input, initiate the conversion process, and transfer the converted data back to the microcontroller. The microcontroller then transforms the data into hex form and transfers the result to the three TIL311 displays. A 74LVC244A octal buffer is used as a buffer between the microcontroller and the displays.

A TL7705 power supply voltage monitor resets the processor at power-on or if the power supply voltage drops below the proper operating level.

Jumper provisions are made to connect the TLV2543 reference voltage to 3.3-V power for ratiometric measurements or to an absolute voltage provided by a TL1431 voltage reference device.

A connector pattern is provided for the user to install an interface connector. An uncommitted breadboard area is also provided. An external 5-V power supply (4.75 V to 5.25 V at 0.5 A) is required for operation.

Hardware Description and Operation

This chapter contains descriptions of the hardware and operation of the TLV2543EVM. This chapter includes the following topics:

Topic	Page
2.1 Setup and Operation	2-2
2.2 Input Select Switch	2-3
2.3 Microcontroller	2-4
2.4 Power Supply Supervisor	2-4
2.5 Optical Sensor	2-5
2.6 Temperature Sensor	2-6
2.7 Voltage Variable Input (Potentiometer)	2-6
2.8 Buffered User Inputs	2-7
2.9 Unbuffered Inputs	2-7
2.10 Reference Select	2-8
2.11 Fast Conversion Rate	2-8
2.12 Input Voltage Clamp	2-8
2.13 Interface Connector Provisions	2-9
2.14 Grounding Considerations	2-9
2.15 Driving the Input of a Switched Capacitor ADC	2-11
2.16 Board Schematic	2-13
2.17 Part Descriptions	2-15

2.1 Setup and Operation

The power supply terminals (J2) on the TLV2543 EVM module must be connected to a regulated 4.75-V to 5.25-V power supply capable of providing at least 0.5 A.

This evaluation module is designed to have power supplied from an external regulated 5-V power supply. No form of power supply regulation is included on the module. Damage to the components can and will occur if the voltage exceeds the maximum specified level. Under voltage can cause improper operation.

When the power supply is switched on, the microcontroller is initialized and the displays flash to indicate proper operation. The displays then show a two or three digit hex value of the voltage generated by the optical sensor and digitized by the TLV2543. The value on the displays varies with the intensity of the light striking the TSL250 sensor (See the *Optical Sensor* section).

The input select switch (S1) is set to the hex address (LSB on the right) which selects the desired TLV2543 input (See the *Input Select Switch* section). The desired A/D converter reference voltage for a given sensor is selected by moving the Ref Select jumper (JP9) to the onboard reference (REF V) position or the power supply (V_{CC}) position.

The TLV2543EVM is shipped with the settings listed in the following table:

Table 2–1. EVM Default Settings

Function	Setting
Input select switch (S1)	0000 hex (optical sensor selected)
Reference select jumper (JP9)	REF V
Input jumpers (JP1, JP2, JP3, JP11, JP12)	Ground
Output jumpers (JP4, JP5, JP6, JP7, JP8)	Shorted
Ref– jumper (JP10)	Shorted

NOTE: The input and output jumpers and the REF– jumper on the TLV2543EVM are formed by a top side copper trace on the PC board between two plated through holes. If desired, the trace can be carefully cut to remove the jumper. The two through holes allow the user to restore the jumper with a wire or connector.

A hole pattern is provided for a user-supplied connector to allow easy application of external analog signals for additional evaluation (See the *Interface Connector Provisions* section).

The following sections give more specific information about each selected sensor input and selected reference.

2.2 Input Select Switch

The four position dip switch (S1) labeled input select allows the user to select the desired analog input of the TLV2543. The switch is treated as a hex address command (MSB on left, LSB on right) as listed in the following table:

Table 2–2. Input Select Switch Descriptions

Hex	Binary	Function Selected	Typical Response
0h	0000	Optical sensor input	User controlled light intensity
1h	0001	Temperature sensor input	588h + temperature change
2h	0010	Potentiometer input	User adjusted
3h	0011	IN3 buffer input	000h or user input
4h	0100	IN4 buffer input	000h or user input
5h	0101	IN5 buffer input	000h or user input
6h–Ah	0110–1010	IN6 through IN10 inputs	000h or user input
Bh	1011	(V_{ref} input)/2 test	800h
Ch	1100	$-V_{ref}$ input (ground) test	000h
Dh	1101	V_{ref} input test	FFFh
Eh	1110	Enter power down mode	Display blank
Fh	1111	Fast conversion rate on IN4 input	User input

Note: Inputs IN3 through IN10 are made available to a user supplied connector (see the *Interface Connector Provisions* section).

2.3 Microcontroller

The TMS370C712 microcontroller (U4) samples the status of the input select switch on ports A4 through A7. This sample data, which is sent to the TLV2543 through the serial peripheral interface ports SPICLK, SPISIM0, and SPISOM1, determines which specific multiplexer input is converted. The microcontroller then reads back the converted 12 bits and changes the data into three hexadecimal digit values. The hexadecimal data is transferred to the three hexadecimal displays U7, U8, and U9. Five sections of the 74LVC244A octal buffer are used to drive the common bused TTL inputs of the displays.

For all input select positions except Fh, the microcontroller instructs the TLV2543 to perform the analog-to-digital conversions and display the results at a rate of approximately 2 conversions per second. When the Input Select position is Fh, the microcontroller selects input IN4 and the conversions from the TLV2543 are at a rate of approximately 30k conversions per second (See the *Fast Conversion Rate* section).

NOTE: The following information applies to the TMS370C712 serial peripheral interface (SPI) to the TLV2543.

The TLV2543 strobcs in the command data bits from the microcontroller on the DIN port at the rising edge of the clock pulse on the I/O CLK terminal. The TMS370C712 generates a clock rising edge on the SPICLK port and also at that time, while conforming to the SPI interface requirements, the data output on the SPISIM0 port changes to reflect the next serial bit to be transferred.

If the SPICLK output is connected directly to the TLV2543 I/O CLK input, the required data setup time for the data to be present before a rising clock edge is applied cannot be less than 100 ns (see the *TLV2543* data sheet). To solve this race condition, a resistor (R24) and capacitor (C21) provide a delay to the rising clock edge. One buffer section of the 74LVC244A octal buffer (U6) is used to buffer the delayed clock signal. If only one TLV2543 is being used (as with this EVM), the buffer is not normally required. If several TLV2543 devices are being driven in a bus configuration, using this buffer is advised.

2.4 Power Supply Supervisor

Power supply voltage is monitored by the TL7705 (U5). When power is first applied, a microprocessor reset is held until the power supply voltage exceeds 4.55 V (nominal). The reset is then released and the microprocessor begins operation.

During normal operation, if the power supply voltage falls below 4.55 V, a reset is activated again.

2.5 Optical Sensor

The TSL250 (U1) optical sensor is connected to the AIN0 multiplexer analog input port of the TLV2543. This sensor converts light intensity to an output voltage ranging from less than 10 mV (dark) to about 2 V (at 2 mW/sq cm illumination intensity).

The output of the optical sensor can be varied by placing an object such as a dark colored plastic marker pen cap over the sensor.

A practical application such as sorting can be demonstrated by holding similar objects of differing shades within the optical viewing range of the sensor (under a uniform intensity light) and noting the displayed values. A simple optical hood to mask ambient light (e.g. drill a hole in the side of the marker pen cap) provides more uniform results.

NOTE: Office light generated by typical artificial lighting contains a high component of ac line frequency intensity variations not normally perceived by the human eye. These variations are detected by the optical sensor. Since the ADC is commanded to make measurements at random times with respect to the ac line frequency, the converted values appear to be unstable in the lower order bits, even though each individual measurement is accurate. This line frequency light intensity variation can be minimized by using dc power to drive the dominate light source (light emitting diodes work well) in addition to shielding the sensor from the ac driven room lighting.

An extension of the sorting concept can yield a simple color sorting sensor system. This system requires three optical sensors, each masked by a red, blue, or green optical filter. The individual readings from the three sensors can then be calibrated to the specific color of the object to be identified. For repeatable results, the intensity and color content of the illuminating light source must be uniform.

2.6 Temperature Sensor

When a single transistor and the 12-bit A/D conversion range of the TLV2543 are used, the following characteristics can be seen:

- A simple temperature sensor
- The textbook temperature variation of a transistor base-emitter junction
- The dc temperature instability of a simple one-transistor amplifier

The 2N2222A transistor (Q1) is connected in a classical feedback amplifier configuration that forces the collector voltage to a base-emitter junction voltage of $2 V_{be}$. The base-emitter junction (essentially a forward biased diode) voltage is about 0.7 V at room temperature (25°C) and has a temperature variation of about $-2.2 \text{ mV}/^{\circ}\text{C}$. Therefore at room temperature, the collector voltage is approximately 1.4 V with a decrease of approximately 4.4 mV for each degree of temperature increase.

If the REF select jumper is set to the on-board reference (REF V) position, the conversion reference is set to approximately 2500 mV or 2.5 V. This setting allows the display to decrement approximately 1.6 counts for each mV or about 7 counts per $^{\circ}\text{C}$ of temperature increase.

If the ambient room temperature is approximately 25°C and human body temperature is approximately 38°C , the display should reduce about 91 counts when the transistor is held firmly between two fingers. For a more exact analysis, exact transistor characteristics, absolute reference voltage levels, exact room and finger temperatures, etc. would have to be taken into account.

2.7 Voltage Variable Input (Potentiometer)

The IN2 input is controlled by a potentiometer (R13). One section of the TLC2264 (U2) serves as a buffer amplifier for the AIN2 TLV2543 input port. When the potentiometer is adjusted over its range, the input voltage changes from 0 to $V_{CC}/2$ (approximately $3.3 \text{ V}/2 = 1.65 \text{ V}$). Since the buffer amplifier has a gain of 2, the input to the TLV2543 port varies from 0 to V_{CC} .

For ratiometric measurements, the REF select jumper should be set to the V_{CC} position. Then the TLV2543 reference becomes V_{CC} and all A/D conversions are made relative to the value of V_{CC} . The potentiometer output voltage, by its connection, is also relative to V_{CC} . An A/D conversion of that voltage yields a value proportional to the setting of the potentiometer and independent of the power supply voltage.

2.8 Buffered User Inputs

The IN3 input is connected to the TLV2543 input port through unity gain configured buffer amplifiers (one section of the TLC2264, U2). Although providing unity gain (gain = +1), the input signal can only be within approximately 1.5 V (see the common mode input voltage range specifications of the TLC2264) of the power supply voltage to maintain predictable operation. As long as the power supply voltage to the TLC2264 remains at 3.3 V, this restricts the usable signal input voltage range from 0 V to 1.8 V, however this range can be acceptable for some input level requirements.

The input impedance is dictated by the 10 k Ω value of resistor R14 and can be changed to almost any suitable value due to the extremely high input impedance of the TLC2264.

Inputs IN4 and IN5 are connected to the TLV2543 input ports, each through a buffer stage of the TLC2264, and each with a gain of 2. The full output voltage swing of 0 V to 3.5 V to the ADC inputs is achieved with signal inputs of 0 V to 1.65 V as listed in Table 2–3.

Table 2–3. Buffered User Input Descriptions

Input	Gain	Unbuffered	Input Range
IN3	$\times 1$	N	0 V – 1.8 V (input to ADC is 1.8/3.3 of full scale)
IN4	$\times 2$	N	0 V – 1.65 V
IN5	$\times 2$	N	0 V – 1.65 V
IN6		Y	0 V – 3.3 V
IN7		Y	0 V – 3.3 V
IN8		Y	0 V – 3.3 V
IN9		Y	0 V – 3.3 V
IN10		Y	0 V – 3.3 V

2.9 Unbuffered Inputs

The IN6 through IN10 inputs are connected to ground by the top side circuit board etch jumpers JP1, JP2, JP3, JP12, and JP11, respectively. Any etch jumper can be removed by carefully cutting the copper trace between the feed-through holes at the JP marking, allowing that input to be connected to an external signal.

When these unbuffered inputs are used, the required TLV2543 specifications such as a low source impedance (see the *Driving the Input of a Switched Capacitor ADC* section) and input voltage range (0 V to 3.3 V) must be used. The signal grounds should not be improperly connected to the high current power supply grounds (see the *Grounding Considerations* section).

2.10 Reference Select

The REF select jumper is provided to allow ratiometric measurements (jumper set to V_{CC}) or allow absolute measurements (jumper set to REF V) relative to a voltage reference established by the TL1431 (D1). This voltage reference is approximately 2.5 V.

Ratiometric measurements are made relative to the 3.3-V power supply voltage. If a sensor or input signal voltage is used that varies proportional to the 3.3-V power supply voltage (such as the potentiometer R13), then the signal becomes a ratio of the absolute value of the power supply voltage. Then, if the reference voltage is connected to 3.3 V (REF SELECT jumper position at V_{CC}), the TLV2543 tracks the power supply voltage and provides a converted result independent of the power supply voltage variations.

Absolute measurements are required if the sensor or input analog signal does not change with the power supply voltage. The previously described optical and temperature sensors are in this category. For these sensors, the REF select jumper is set to the REF V position.

2.11 Fast Conversion Rate

When the input select switch is set to Fh, the EVM module operates in a fast conversion rate mode. In this mode, the conversion rate is approximately 30k conversions per second from the IN4 input. The displays are updated once every 20 conversions.

2.12 Input Voltage Clamp

The TL7726 (VZ1) is connected to inputs IN3 through IN8. The TL7726 clamps an input signal voltage in excess of the power supply voltage level to prevent damage to the semiconductor inputs. Signal voltages below 0 V (ground) are clamped to ground. Signal inputs between 3.3 V and ground are not affected. The TL7726 provides protection for inputs from incidental transients due to static discharge, excessive signals, etc. Transient current protection is limited to 25 mA.

2.13 Interface Connector Provisions

A hole pattern for a user-supplied interface connector is provided at J1. A standard 8×2 set of header posts (such as an AMP 87215-5 or Molex 10-89-1161) can be soldered in place. This arrangement allows several different styles of connector to be installed as necessary to satisfy user requirements.

Figure 2–1. Interface Connector Hole Pattern




Table 2–4. Interface Connector Hole Pattern Descriptions

Hole	Circuit Function
1	NC
2	NC
3	IN3 input (buffered with +1X gain)
4	IN4 input (buffered with +2X gain)
5	IN5 input (buffered with +2X gain)
6	IN6 input
7	IN7 input
8	IN8 input
9	IN9 input
10	IN10 input
11	5 V
12	Signal ground
13	5 V
14	Power ground
15	5 V
16	Power ground

Note: Hole 12 can be used as a signal ground return to avoid the higher current ground return paths that are associated with a power supply ground.

2.14 Grounding Considerations

When designing analog circuits that share a ground with digital and high current power supplies, the voltage drop along the high current paths must be taken into account. This voltage drop is a result of the current flowing through the greater-than-zero resistance of the current path, and/or high frequency current transients flowing through the greater-than-zero inductance of a current path.

If the signal ground is connected to the power supply ground at the improper location, this voltage drop is injected into the signal ground and appears as part of the signal, causing an error.

The solution is to establish a single ground point on the PC board and connect all grounds individually to that point (the EVM single ground point is at the GND terminal of the power supply connector). By using this method, currents flowing along any one path to ground do not inject error voltages in any other ground path.

As a practical implementation, however, it may not be reasonable to run a separate ground trace for each component that connects to ground. Therefore, the next best approach is to group the higher current grounds (such as the power supply and digital grounds) together and run them to the central PC board ground point, while still maintaining separate ground paths for the analog grounds.

An analysis of current flow paths within the analog section will give an indication of which grounded components could be lumped together into a common ground path and which should be kept separate. For instance, on the EVM, it would be reasonable to use a common path for the TLV2543 REF-terminal and the TL1431 anode. This is because the only significant current flow is through the TL1431 (only about 1 mA) and is not enough to cause a significant error. A 1/2 LSB error at a reference voltage of 2.5 V would be about 0.3 mV, so the ground trace would have to be in excess of 0.3 Ω to cause such an error.

If all of the input signals are low current, such as the optical sensor (about 2 mA), the temperature sensor (about 1 mA) and the potentiometer (about 0.25 mA), it may be reasonable to use a common ground trace. As always, wider trace widths are desirable to keep the resistance low. If high currents are associated with any input signal, always use a separate PC board trace directly to the central ground point location.

Even though the operating current of the TLV2543 is low (2.5 mA max), some high speed current transients due to the internal digital switching are present and a separate ground trace is reasonable.

Note:

Always keep the power supply decoupling capacitor as close as possible to the supply pins. This means that the separate ground trace would actually be for the decoupling capacitor and the TLV2543 ground pin.

If free area is available, or if the PC board is multilayer, a large ground plane may be acceptable to connect all the analog side ground connections providing that any one signal ground connection is not carrying a large current. That ground plane should be connected directly to the central ground point without touching any of the digital or power supply ground locations along its path.

Treating the distribution of the digital and analog 5-V and 3.3 V current paths on the PC board in a similar manner to the grounds is also a good practice. The designated central power point location is the 5-V terminal of the power supply connector (J2) on the EVM board.


2.15 Driving the Input of a Switched Capacitor ADC

When applying an analog signal to the input of a switched capacitor ADC such as the TLV2543, care must be taken to provide a low enough impedance to the input terminal to charge the internal capacitor enough for an accurate conversion during the sampling phase of the converter. The sampling time will depend on the period of the I/O clock rate being used to drive the converter and the number of transfer bits commanded. With the maximum I/O clock frequency of 4.1 MHz and a 12-bit transfer mode, the TLV2543 uses 8 clock cycles (or about 2 μ s) for the sampling time.

The input equivalent circuit of the TLV2543 looks like a series resistance and a capacitor to ground during sampling and an open circuit during conversion.

For accurate operation the input capacitor must be charged to the required accuracy of 1/2 LSB (or more, depending on the required system error budget) during the sampling phase of the ADC cycle.

Figure 2–2. Equivalent Input Circuit



The voltage on capacitor C1 is given by:

$$V_C = V_S \left(1 - e^{-t/TC} \right) \quad (1)$$

Where TC is the time constant $C1(R_S + R1)$

The final voltage value of V_C within 1/2 LSB of V_S is

$$V_C (1/2 \text{ LSB}) = V_S - V_S / 2^{n+1} \quad (2)$$

Where n is the resolution of the converter.

So equating equation 1 to equation 2 then

$$V_S - V_S / 2^{n+1} = V_S \left(1 - e^{-t/TC} \right)$$

therefore the charging time in terms of the circuit time constants is

$$t (1/2 \text{ LSB}) = TC \ln(2^{n+1})$$

For a 12-bit converter this would be:

$$t_s = TC \times \ln(8192) = 9 \text{ TC}$$

The internal capacitance for the TLV2543 is 60 pF max and the internal series resistance is 1 K Ω . Therefore, with an I/O clock at 4.1 MHz, and a 12-bit transfer mode (sample period = 2 μ s), the time constant should be no more than:

$$1/9 \times 2 \mu\text{s} = 0.22 \mu\text{s}$$

Therefore

$$C1(Rs+R1) = 0.22 \mu\text{s}$$

So

$$(Rs+R1) = 3.67 \text{ K}\Omega$$

Since $R_s = 1\text{K}$, then the source impedance should be less than 2.67 K Ω to stay within 1/2 LSB error. Good design practice dictates that the source impedance be as low as possible, such as the output of an op-amp. However in an application where fast conversion time is not critical, slow I/O clock rates can allow the driving source impedance to be relatively large.

2.16 Board Schematic

The schematic of the EVM is shown in the following figure.

Figure 2–3. Board Schematic





Figure 2–3 Board Schematic (continued)



2.17 Part Descriptions

A list of the TLV2543EVM parts are listed in the following table.

Table 2–5. Part Descriptions

Number	Quantity	Reference	Description
1	1	C1	100 μ F, 16V Aluminum
2	14	C2, C3, C4, C5, C7, C8, C12, C13, C14, C15, C16, C17, C18, C19	0.1 μ F Ceramic, Z5U, 0.2 Inch
3	2	C20	10 μ F, 6.3 V Tantalum, 0.2 Inch
4	2	C9, C6	10 μ F, 10 V Alum
5	2	C10, C11	15 pF Ceramic, NPO, 0.2 Inch
6	1	C21	47 pF
7	1	D1	TL1431ACLP
8	1	JP9	3 Pin Header
9	1	JP9	Shorting jumper, 2 Pin
10	1	J2	Terminal block, 2 Pos, 5 mm, side entry (OST ED1601)
11	1	Q1	2N2222A (T0-18 metal can)
12	16	R1, R2, R3, R4, R5, R10, R11, R12, R14, R15, R16, R17, R18, R19, R20	10K Ω , 1%, 0.25 W
13	1	R6	499 Ω O
14	2	R7, R8	49.9K Ω
15	1	R9	4.99K Ω
16	1	R21, R24	1K Ω
17	1	R25	1 Ω
18	1	R13	10K Ω Pot, single turn, top adj, 3/8 inch sq (Bourns 3386 P)
19	1	S1	DIP switch, 4 pos, Gold
20	1	U1	TSL250
21	1	U2	TLC2264
22	1	U3	TLV2543 (3V)
23	1	U4	TMS370C712
24	1	U5	TL7705B
25	1	U6	74LVC244A
26	3	U7, U8, U9	TIL311
27	1	U10	TPS7233Q (SOJC)
28	1	VZ1	TL7726
29	1	Y1	12 MHz crystal, HC-49/ μ s
30	1		PC board, TLV2543 EVM

R22, R23, C4, C5 designations unused



Software Program and Flowcharts

The TLV2543EVM uses a TI TMS370C712 microcontroller to interface with the TLV2543 ADC. The program reads a four position DIP switch to determine which input is selected to be digitized. The program then uses the onboard SPI interface to communicate with the TLV2543. Sixteen bits of data (12 significant bits and 4 fill bits) are read into the processor and output on the three LED displays. This is repeated approximately every 0.5 seconds.

A fast mode can also be selected with the DIP switch. In this mode, channel four is selected as input and 20 samples are taken at about a 30 kHz rate, data is converted and displayed, and the process is repeated until another input is selected with the DIP switch. A power-down mode can also be selected which places the TLV2543 in a power-down mode and blanks the display.

This chapter includes the following topics.

Topic	Page
3.1 Software Program	3-2
3.2 Flowcharts	3-8

3.1 Software Program

TMS370 Macro Assembler Version 5.20 Thu Aug 17 17:20:54 1995
Copyright (c) 1986-1995 Texas Instruments Incorporated

adc_evm.asm

PAGE 1

```
1          ;;;;;;;;;;;;;;
2          ;
3          ; TLV2543 EVALUATION MODULE PROGRAM
4          ;
5          ;     VERSION 1.2   8/17/95
6          ;
7          ;     THIS PROGRAM READS A FOUR POSITION DIP
8          ;     SWITCH WHICH IS USED TO SELECT THE INPUT
9          ;     SIGNAL CHANNEL TO THE ADC.  THE PROGRAM
10         ;     THEN SELECTS THIS CHANNEL ON THE ADC AND
11         ;     CONVERTS THE ANALOG INPUT TO A 12 BIT
12         ;     HEX NUMBER AND OUTPUTS THE RESULTS ON
13         ;     3 7-SEGMENT DISPLAYS. POSITIONS ARE ALSO
14         ;     PROVIDED TO PUT THE ADC IN A POWER DOWN
15         ;     MODE AND A FAST MODE (APPROX 26 KHZ RATE).
16         ;
17         ;;;;;;;;;;;;;;
18         ;;;;;;;;;;;;;;
19         ;
20         ; SYSTEM EQUATES
21         ;
22         ;;;;;;;;;;;;;;
23         ;
24         ; SERIAL PERIPHERAL INTERFACE (SPI) REGISTERS
25         ;
26         0030 SPICCR .EQU   P030   ;SPI CONFIG REG
27         0031 SPICTL .EQU   P031   ;SPI OPERATION CONTROL REG
28         0037 SPIBUF .EQU   P037   ;SPI INPUT BUFFER
29         0039 SPIDAT .EQU   P039   ;SPI SERIAL DATA REG
30         003d SPIPC1 .EQU   P03D   ;SPI PORT CONTROL REG1
31         003e SPIPC2 .EQU   P03E   ;SPI PORT CONTROL REG2
32         003f SPIPRI .EQU   P03F   ;SPI INTERRUPT CONTROL REG
33         ;
34         ; PORT A AND D REGISTERS
35         ;
36         0021 APORT2 .EQU   P021   ;PORT A CONTROL REG
37         0022 ADATA  .EQU   P022   ;PORT A DATA
38         0023 ADIR   .EQU   P023   ;PORT A DIRECTION
39         002c DPORT1 .EQU   P02C   ;PORT D CONTROL REG1
40         002d DPORT2 .EQU   P02D   ;PORT D CONTROL REG 2
41         002e DDATA  .EQU   P02E   ;PORT D DATA
42         002f DDIR   .EQU   P02F   ;PORT D DIRECTION
43         ;
44         ; TIMER 1 DEFINITIONS
45         ;
46         0040 T1CNTR1 .EQU   P040   ;MSB OF COUNTER
47         0041 T1CNTR2 .EQU   P041   ;LSB OF COUNTER
48         0042 TC11    .EQU   P042   ;MSB OF COMPARE REGISTER
49         0043 TC12    .EQU   P043   ;LSB OF COMPARE REGISTER
50         0049 T1CTL1  .EQU   P049   ;TIMER 1 CONTROL REG 1
51         004a T1CTL2  .EQU   P04A   ;TIMER 1 CONTROL REG 2
52         004b T1CTL3  .EQU   P04B   ;TIMER 1 CONTROL REG 3
53         ;
54         ; BIT DEFINITIONS
55         ;
```

adc_evm.asm

PAGE 2

```
56      2e      CSBIT  .DBIT  3,DDATA  ;ADC CHIP SELECT BIT
57      31      SPIF   .DBIT  6,SPICTL ;SPI INTR FLAF
58      2e      DOUT1  .DBIT  5,DDATA  ;STROBE FOR DISPLAY 1
59      2e      DOUT2  .DBIT  6,DDATA  ;STROBE FOR DISPLAY 2
60      2e      DOUT3  .DBIT  7,DDATA  ;STROBE FOR DISPLAY 3
61      2e      DBLANK .DBIT  4,DDATA  ;BLANK STROBE
62      4a      RST    .DBIT  0,T1CTL2 ;SW TIMER RESET
63      4b      TOUT   .DBIT  5,T1CTL3 ;TIMER 1 TIME OUT
64      ;
65      ;;;;;;;;;;;;;;
66      ;
67 6000      .TEXT  6000H  ;START OF PROGRAM
68      ;
69      ;;;;;;;;;;;;;;
70      ;
71      ; MAIN PROGRAM
72      ;
73 6000      5260     START  MOV    #60H,B
74 6002      fd      LDSP   ;SET STACK POINTER TO 60H
75 6003      '8e6014 CALL  INIT  ;INITIALIZE SYSTEM
76      ;
77 6006      '8e6056 LOOP  CALL  READSW ;READ INPUT DIP SWITCH
78 6009      '8e60ed CALL  ADC   ;DIGITIZE INPUT
79 600c      '8e614d CALL  DISPLAY ;DISPLAY VALUE
80 600f      '8e6126 CALL  DELAY ;DELAY .5 SEC
81 6012      '00f2     JMP   LOOP
82      ;
83      ;;;;;;;;;;;;;;
84      ;;;;;;;;;;;;;;
85      ;
86      ; INIT
87      ;
88      ; THIS ROUTINE INITIALIZES PORTS A AND
89      ; D, SETS UP THE SPI, AND INITIALIZES
90      ; THE DISPLAYS BY FLASHING 8 AND 0 THREE
91      ; TIMES.
92      ;
93 6014      f70021  INIT  MOV    #0,APORT2 ;SET PORT A TO I/O
94 6017      f70f23 MOV    #0FH,ADIR  ;SET A4-A7=INPUT, A0-A3=OUTPUT
95 601a      f7002c MOV    #0,DPORT1  ;SET PORT D TO I/O
96 601d      f7002d MOV    #0,DPORT2
97 6020      f7f82f MOV    #0F8H,DDIR ;SET D3-D7 OUTPUTS
98      ;
99 6023      f78030 MOV    #80H,SPICCR ;INIT SPI
100 6026      f70730 MOV    #07H,SPICCR ;SET CLOCK, 8BIT CHAR LEN
101 6029      f7033d MOV    #03H,SPICP1 ;SET SPI CLK TO OUTPUT
102 602c      f7223e MOV    #22H,SPICP2 ;SET SPISOMI AND SPISIMO TO SPI DATA
103      ;
104 602f      720019 MOV    #0,R25     ;CLR CHANNEL REGS
105 6032      72001d MOV    #0,R29
106      ;
107      ; FLASH DISPLAY
108      ;
109 6035      720314 MOV    #03,R20   ;SET LOOP CTR TO 3 CYCLES
110 6038      2208     MOV    #08H,A    ;SET DISPLAY REGS TO 8
```

```

111 603a  d01a      MOV     A,R26
112 603c  d01b      MOV     A,R27
113 603e  d01c      MOV     A,R28
114 6040  '8e614d    LOOP1  CALL   DISPLAY
115 6043  720218    MOV     #02H,R24 ;SET DELAY TO .5 SEC
116 6046  '8e6126    CALL   DELAY
117 6049  a4102e    SBIT1  DBLANK  ;BLANK DISPLAY
118 604c  '8e6126    CALL   DELAY
119 604f  a3ef2e    SBIT0  DBLANK  ;TURN OFF BLANK
120 6052  'da14eb    DJNZ   R20,LOOP1 ;JMP BACK IF NOT DONE
121 6055  f9        RTS
122      ;
123      ;;;;;;;;;;;;;;
124      ;;;;;;;;;;;;;;
125      ;
126      READSW
127      ;
128      ; THIS ROUTINE READS THE 4 POSITION DIP
129      ; SWITCH FOR THE CHANNEL NUMBER AND SAVES
130      ; IT IN R29. IF 0EH IS SELECTED THE ADC
131      ; IS PLACED IN A POWER DOWN MODE. IF 0FH
132      ; IS SELECTED THE INPUT ON CHANNEL 4 IS
133      ; CONVERTED IN FAST MODE. ADC CHANNEL NUMBER
134      ; IS STORED IN R25.
135      ;
136      ;
137 6056  8022    READSW  MOV     ADATA,A ;READ SWITCHES
138 6058  b7      SWAP   A ;SWAP NIBBLES
139 6059  230f    AND     #0FH,A
140 605b  1d1d    CMP     R29,A
141 605d  '0601    JNE     READ1 ;JMP IF ADC INPUT CHANGED
142 605f  f9      RTS
143      ;
144      ; ADC INPUT CHANGED - WAIT FOR COMPLETE
145      ;
146 6060  d01d    READ1  MOV     A,R29 ;SAVE IT
147 6062  720318  MOV     #03,R24 ;SET DELAY FLAG TO 2 SEC
148 6065  '8e6126  CALL   DELAY
149 6068  8022    MOV     ADATA,A ;CHECK AGAIN
150 606a  b7      SWAP   A
151 606b  230f    AND     #0FH,A
152 606d  1d1d    CMP     R29,A
153 606f  '06ef    JNE     READ1
154      ;
155      ;SEE IF POWER DOWM MODE
156      ;
157 6071  7d0e1d  CMP     #0EH,R29
158 6074  '061b    JNE     READ2 ;JMP IF NOT POWER DOWN
159 6076  a4102e  SBIT1  DBLANK  ;BLANK DISPLAY
160 6079  a3f72e  SBIT0  CSBIT  ;ENABLE ADC
161 607c  f70631  MOV     #06H,SPICTL
162 607f  f7ec39  MOV     #0ECH,SPIDAT
163 6082  8022    READ3  MOV     ADATA,A ;WAIT FOR CHANGE
164 6084  b7      SWAP   A
165 6085  230f    AND     #0FH,A
    
```



```

166 6087 * 4d001d      CMP      A,R29
167 608a '02f6        JEQ      READ3
168 608c a3ef2e        SBIT0   DBLANK ;CLEAR BLANK
169 608f '00cf        JMP      READ1
170
171 ;
172 ; SEE IF FAST MODE
173 6091 7d0f1d      READ2   CMP      #0FH,R29 ;IS IT FAST MODE
174 6094 '0650        JNE     READ4
175 6096 a3f72e        RLOOP1  SBIT0   CSBIT   ;ENABLE ADC
176 6099 720419        MOV     #04H,R25 ;CHANNEL 4 - FAST MODE
177 609c 224c        MOV     #4CH,A ;CHANNEL 4,16BITS,MSB 1ST
178 609e 721414        MOV     #20,R20 ;DO 20 FAST THEN UPDATE
179 60a1 f70631        MOV     #06H,SPICTL
180 60a4 2139        RLOOP2  MOV     A,SPIDAT
181 60a6 'a74031fc      RFLG1   JBIT0   SPIF,RFLG1 ;WAIT FOR DATA
182 60aa a21537        MOV     SPIBUF,R21
183 60ad 2139        MOV     A,SPIDAT
184 60af 'a74031fc      RFLG2   JBIT0   SPIF,RFLG2 ;WAIT FOR DATA
185 60b3 a21637        MOV     SPIBUF,R22
186 60b6 ff          NOP
187 60b7 ff          NOP ;GIVE TIME FOR
188 60b8 ff          NOP ; CONVERSION TO
189 60b9 'da14e8        DJNZ   R20,RLOOP2 ; COMPLETE
190 ;DISPLAY VALUE
191 60bc 42151a        MOV     R21,R26
192 60bf d71a        SWAP   R26
193 60c1 730f1a        AND     #0FH,R26 ;SAVE MSDIGIT IN R26
194 60c4 42151b        MOV     R21,R27
195 60c7 730f1b        AND     #0FH,R27 ;SAVE MIDDLE DIGIT IN R27
196 60ca 42161c        MOV     R22,R28
197 60cd d71c        SWAP   R28
198 60cf 730f1c        AND     #0FH,R28 ;SAVE LSDIGIT IN R28
199 60d2 '8e614d        CALL   DISPLAY
200 60d5 a4082e        SBIT1   CSBIT   ;DISABLE ADC
201 ;SEE IF FAST MODE STILL SELECTED
202 60d8 8022        MOV     ADATA,A ;WAIT FOR CHANGE
203 60da b7          SWAP   A
204 60db 230f        AND     #0FH,A
205 60dd * 4d001d      CMP     A,R29
206 60e0 '02b4        JEQ     RLOOP1
207 60e2 *'89ff7b      JMP     READ1
208 60e5 f9          RTS
209 ;
210 ; SETUP CHANNEL # IN R25
211 ;
212 60e6 421d19      READ4   MOV     R29,R25
213 60e9 720218        MOV     #02,R24 ;SET DELAY TO .5SEC
214 60ec f9          RTS
215 ;
216 ;;;;;;;;;;;;;;
217 ;;;;;;;;;;;;;;
218 ;
219 ; ADC
220 ;

```

```

221          ;          THIS ROUTINE DIGITIZES THE INPUT ON
222          ;          THE CHANNEL SPECIFIED IN R25.  THE RESULTS
223          ;          ARE PLACED IN REGISTERS R26, R27, AND R28.
224          ;
225 60ed     1219      ADC      MOV      R25,A
226 60ef     b7       SWAP     A
227 60f0     23f0     AND      #0F0H,A ;CHANNEL # IN MS NIBBLE
228 60f2     240c     OR       #0CH,A ;16 BITS, MSB 1ST, BINARY
229 60f4     a3f72e   SBIT0   CSBIT   ;ENABLE ADC
230 60f7     f70631   MOV      #06H,SPICTL
231 60fa     2139     MOV      A,SPIDAT
232 60fc     'a74031fc ADCFLG1 JBIT0   SPIF,ADCFLG1 ;WAIT FOR DATA
233 6100     a21537   MOV      SPIBUF,R21 ;SAVE MSBYTE
234 6103     2139     MOV      A,SPIDAT
235 6105     'a74031fc ADCFLG2 JBIT0   SPIF,ADCFLG2 ;WAIT FOR DATA
236 6109     a21637   MOV      SPIBUF,R22 ;SAVE LSBYTE
237          ;
238          ; SAVE DATA
239          ;
240 610c     42151a   MOV      R21,R26
241 610f     d71a     SWAP     R26
242 6111     730f1a   AND      #0FH,R26 ;SAVE MSDIGIT IN R26
243 6114     42151b   MOV      R21,R27
244 6117     730f1b   AND      #0FH,R27 ;SAVE MIDDLE DIGIT IN R27
245 611a     42161c   MOV      R22,R28
246 611d     d71c     SWAP     R28
247 611f     730f1c   AND      #0FH,R28 ;SAVE LSDIGIT IN R28
248 6122     a4082e   SBIT1   CSBIT   ;DISABLE ADC
249 6125     f9       RTS
250          ;
251          ;;;;;;;;;;;;;;
252          ;;;;;;;;;;;;;;
253          ;
254          ; DELAY
255          ;          THIS ROUTINE USES TIMER 1 AS
256          ;          A GENERAL PURPOSE TIMER TO
257          ;          DELAY 0, .5, OR 2 SECONDS.
258          ;          R24 IS SET AS FOLLOWS:
259          ;          1=0 SEC.
260          ;          2=.5 SEC.
261          ;          3=2 SEC.
262          ;
263 6126     7d0118   DELAY   CMP      #1,R24 ;SEE IF NO DELAY
264 6129     '0601   JNE     DELAY1
265 612b     f9       RTS
266 612c     7d0218   DELAY1  CMP      #2,R24 ;SEE IF .5 SEC DELAY
267 612f     '0614   JNE     DELAY2
268 6131     f71642   MOV      #16H,TC11 ;.5 SEC COMPARE VALUE
269 6134     f7e343   MOV      #0E3H,TC12
270 6137     a40749   DLOOP  OR      #07H,T1CTL1 ;SET PRESCALER TO 256
271 613a     a4014a   OR      #1,T1CTL2 ;START COUNTER AT ZERO
272 613d     a3df4b   SBIT0   TOUT    ;CLR CMP FLAG
273 6140     'a7204bfc DFLAG1  JBIT0   TOUT,DFLAG1 ;WAIT FOR TIMEOUT
274 6144     f9       RTS
275 6145     f75b42   DELAY2  MOV      #5BH,TC11 ;2 SEC COMPARE VALUE
    
```

adc_evm.asm

```
276 6148 f78d43          MOV    #8DH,TC12
277 614b '00ea          JMP    DLOOP
278                      ;
279                      ;;;;;;;;;;;;;;;;;;
280                      ;;;;;;;;;;;;;;;;;;
281                      ;
282                      ; DISPLAY
283                      ;
284                      ; THIS ROUTINE DISPLAYS THE HEX
285                      ; DIGITS STORED IN REGS R26, R27,
286                      ; AND R28.
287                      ;
288 614d 321a          DISPLAY MOV    R26,B          ;OUTPUT LSD
289 614f 'aa6175          MOV    *DTBL[B],A
290 6152 2122          MOV    A,ADATA
291 6154 a3df2e          SBIT0  DOUT1          ;STROBE IT
292 6157 a4202e          SBIT1  DOUT1
293 615a 321b          MOV    R27,B          ;OUTPUT MIDDLE DIGIT
294 615c 'aa6175          MOV    *DTBL[B],A
295 615f 2122          MOV    A,ADATA
296 6161 a3bf2e          SBIT0  DOUT2
297 6164 a4402e          SBIT1  DOUT2
298 6167 321c          MOV    R28,B          ;OUTPUT MSD
299 6169 'aa6175          MOV    *DTBL[B],A
300 616c 2122          MOV    A,ADATA
301 616e a37f2e          SBIT0  DOUT3
302 6171 a4802e          SBIT1  DOUT3
303 6174 f9          RTS
304 6175 00          DTBL  .BYTE 00H      ;0
305 6176 08          .BYTE 08H      ;1
306 6177 04          .BYTE 04H      ;2
307 6178 0c          .BYTE 0CH      ;3
308 6179 02          .BYTE 02H      ;4
309 617a 0a          .BYTE 0AH      ;5
310 617b 06          .BYTE 06H      ;6
311 617c 0e          .BYTE 0EH      ;7
312 617d 01          .BYTE 01H      ;8
313 617e 09          .BYTE 09H      ;9
314 617f 05          .BYTE 05H      ;A
315 6180 0d          .BYTE 0DH      ;B
316 6181 03          .BYTE 03H      ;C
317 6182 0b          .BYTE 0BH      ;D
318 6183 07          .BYTE 07H      ;E
319 6184 0f          .BYTE 0FH      ;F
320                      ;;;;;;;;;;;;;;;;;;
321                      ;;;;;;;;;;;;;;;;;;
322 7ffe          .SECT "RESET",7FFEh      ;RESET VECTOR ADDR
323 7ffe 6000          .WORD 6000H      ;PROGRAM START
324                      ;
325                      .END
```

No Errors, No Warnings

3.2 Flowcharts

The flowcharts for the TLV2543EVM are shown in the following figures.

Figure 3–1. Main Program Flowchart




Figure 3–2. Initialization Subroutine Flowchart




Figure 3–3. Read Input Switch Subroutine Flowchart




Figure 3-3 Read Input Switch Subroutine Flowchart (continued)




Figure 3–4. Analog-to-Digital Convert Subroutine Flowchart




Figure 3-5. Delay Subroutine Flowchart




Figure 3–6. Display Subroutine Flowchart

